

GAZ MIXER

# MIXOJET 30

SAFETY INSTRUCTIONS FOR USE AND MAINTENANCE

DEVICE N° 0409 1173



EDITION: GB  
REVISION: D  
DATE: 03-2006

Instructions for use

REF: **8695-4871**  
DS: 161-6

# INFORMATIONS

## DISPLAYS AND PRESSURE GAUGES

The measuring devices or displays for voltage, current, speed, pressure, etc., whether analog or digital, should be considered as indicators

---

## REVISIONS

### REVISION B

05/03

DESIGNATION	PAGE
Update	23, 27, 36, 41.

### REVISION C


03/06

DESIGNATION	PAGE
Normatec 0409 1190	43

### REVISION D

03/06

DESIGNATION	PAGE
Change logo	



			✓	normally in stock
			✗	not in stock
				on request
Item	Ref.	Stock	Order	Designation
A1	0800 0325	✓		Black pipe, inner Ø 10 mm (N <sub>2</sub> ), length 10 metres
A2	7001 2026	✓		Olive + G 3/8D nut assembly.
A3	0800 0313	✓		Blue pipe, inner Ø 10 mm (O <sub>2</sub> ), length 10 metres
A4	7001 2021	✓		Olive + M16 x 150 D nut assembly
A5	0800 0322	✓		Orange pipe, inner Ø 10 mm (CH <sub>4</sub> ), length 10 metres
A6	7001 2027	✓		Olive + G 3/8/G nut assembly
A7	7001 2020	✓		Olive + M16 x 150 G nut assembly (Mix)
E1				3-POSITION SWITCH → CROUZET.
				Black button ref. 2467 9177
				NC Valve ref. 8954 4501
G2	0409 1190	✓		Output pressure gauge, 0-10 bar.
G3	0409 1190	✓		CH <sub>4</sub> flow meter. Fitted and adjusted
G4	0712 1488	✓		Flame-resistant valve (N <sub>2</sub> O <sub>2</sub> )
G5	0712 1489	✓		Flame-resistant valve (CH <sub>4</sub> )
G10				Red valve (CH <sub>4</sub> )
G12	0409 1191	✓		Input pressure gauge 0-16 bar
G13	0409 1191	✓		Input pressure gauge 0-16 bar
G14	0409 1191	✓		Input pressure gauge 0-16 bar
			▲	

➤ For parts order, give the quantity required and put the number of your machine in the box below.

CE Type Matricule	TYPE :	TYPE:.....
	Matricule :	Number: .....