

## GUARANTEE

This **Clarke** product is guaranteed against faults in manufacture for 12 months from purchase date.

Keep your receipt as proof of purchase.

This guarantee is invalid if the product has been found to have been abused in any way, or not used for the purpose for which it was intended, or to have been tampered with in any way.

Where possible return faulty goods to the place of purchase.

No products should be returned to us without our prior permission.


The reason for return must be clearly stated.

This guarantee does not effect your statutory rights.


## CONTENTS

Safety Precautions .....	3
No Gas Mig Welding - How it works .....	3
Benefits of No Gas Mig Welding .....	3
Welder specifications .....	4
Wiring .....	4
Assembly .....	5
Connecting the wire feed .....	7
Conversion to gas welding .....	9
Preparation for welding .....	10
Welding procedures .....	10
Wire size specifications charts .....	10 - 11 - 12 - 13
Replacing the spool of wire .....	14
Replacement welding wire and gas bottles .....	14
Welding hints and maintenance .....	14
Spot welding .....	14
Welding techniques .....	15
Tuning the welder .....	15
Types of joints .....	16
Drawings & parts list .....	17 - 18
Wiring diagrams .....	18-19


## WIRING DIAGRAM MIG 90 EN NO GAS



## MIG 100 EN NO GAS



## MIG 150 EN NO GAS



\*\* North America 220 V., 60 Hz