



**COMMERCIALLY CONFIDENTIAL**

# **Injector Despatch Number List**

## **1. INTRODUCTION**

The injector despatch number list contains identification and working pressure information for injectors supplied by Delphi Diesel Systems. The injectors are listed in despatch number order. The significance of the lettering and numbering of injectors is detailed in the injector workshop manual DDNX118 and in Service Instruction Note DT159.

Settlement will occur during the early working life of an injector resulting in some loss of opening pressure, particularly if a nozzle or spring has been replaced. The following notes give the recommended allowances.

### **Tolerances**

A nozzle opening pressure setting tolerance is allowable on all injectors according to type as follows:

Screw adjusted injectors    + 5   - 0 bar

Shim adjusted injectors     + 8   - 0 bar

### **Working/Setting pressure**

The nozzle opening pressure stated is that at which the injector is intended to work in the engine termed 'working pressure'. When servicing injectors, allowance should be made for settlement by re-setting the opening pressure at the higher end of the tolerance termed 'setting pressure'.

Additionally, if a new nozzle or spring has been fitted, the following allowance above the working pressure should be made. The following table is intended as a guide:-

<b>New Component Fitted</b>	<b>Allowance above specified working pressure</b>
Nozzle	5 Bar
Spring	5 Bar
Nozzle and Spring	10 Bar

e.g. Injector 5238404 serviced by dismantling and cleaning only would be reset to its working pressure of 177 + 5   - 0 bar. If fitted with a new nozzle and spring, additional allowance should be made and the setting pressure raised to 187 + 5   - 0 bar.

## 2. GENERAL INFORMATION

### Identification tabs

Certain types of injector are fitted with a tab washer beneath the nozzle capnut, the tab detailing the engine manufacturer's identification. Other types of injector carry a roll-marked identification on the upper part of the nozzle holder body. Identification by either of these methods is shown in the 'Tab code' column.

### Nozzle holder identification

Nozzle holder dispatch numbers comprise the first five or four digits of the complete dispatch number depending on the injector type.

e.g. 52174 is the dispatch number for the nozzle holder fitted to injector 5217412, 001R is the dispatch number for the nozzle holder fitted to injector 001R02B and B009 is the dispatch number for the nozzle holder fitted to injector B00901A.

### Injector types

The injector list also includes 2-stage, instrumented and common rail injectors. In these cases the working pressure is not specified but in some instances cross-referred to a Service Instruction Note.

Injector Desp No.	Holder Desp No.	Holder Type Symbol No.	Nozzle Desp No.	Nozzle Type Symbol No.	Injector Working Pressure ( Bar )	Tab Code
5112301	51123	BKC30SD666	5641015	BDN0SD21	121	
5112302	51123	BKC30SD666	5641033	BDN0SD211	121	
5113601	51136	BKC37S5372	5643420	BDN4SD6637	126	
5113602	51136	BKC37S5372	5643849	BDN0SDZ6577	126	
5113603	51136	BKC37S5372	5641892	RDN0SD6754	132	
5113701	51137	BKC37S5372A	5643849	BDN0SDZ6577	101	
5113702	51137	BKC37S5372A	5643849	BDN0SDZ6577	126	
5113901	51139	BKC37S5465	5641892	RDN0SD6754	131	
5113902	51139	BKC37S5465	5643849	BDN0SDZ6577	122	
5114401	51144	BKC45SD21C	5642001	BDN4S1	126	
5114403	51144	BKC45SD21C	5643014	BDN12SD12	131	
5114901	51149	BKC45S25C	5643059	RDN4SD6164	131	
5115001	51150	BKC45S5416	5643014	BDN12SD12	123	
5115101	51151	BKC45S5464	5641892	RDN0SD6754	130	
5123301	51233	BKC57SD5014	5641048	BDN0SD6191	162	
5123401	51234	BKC57SD5014H	5641048	BDN0SD6191	177	
5131601	51316	NLA72S8	5620680	BDLL150S6028	177	
5131602	51316	NLA72S8	5620705	BDLL150S6064	177	
5131603	51316	NLA72S8	5620695	BDLL150S6054	177	
5131604	51316	NLA72S8	5621078	BDLL150S6324	177	
5131605	51316	NLA72S8	5621212	BDLL150S6397	177	
5132501	51325	NLA72S15	5621112	BDLL150S6369	177	
5132502	51325	NLA72S15	5620695	BDLL150S6054	177	
5132503	51325	NLA72S15	5621212	BDLL150S6397	162	
5132504	51325	NLA72S15	5621076	BDLL150S6324	160	
5132505	51325	NLA72S15	5621506	BDLL150S6468	177	
5132506	51325	NLA72S15	5621212	BDLL150S6397	177	
5133601	51336	NLA97S6	5620590	BDLL150S660	177	
5135101	51351	NLA102S8	5620680	BDLL150S6028	177	

Injector Desp No.	Holder Desp No.	Holder Type Symbol No.	Nozzle Desp No.	Nozzle Type Symbol No.	Injector Working Pressure ( Bar )	Tab Code
5135102	51351	NLA102S8	5620705	BDLL150S6064	177	
5135103	51351	NLA102S8	5620695	BDLL150S6054	177	
5135104	51351	NLA102S8	5620925	BDLL150S6211	177	
5135105	51351	NLA102S8	5621074	BDLL150S6318	177	
5135106	51351	NLA102S8	5620790	BDLL150S6130A	177	
5135107	51351	NLA102S8	5621113	BDLL150S6369A	177	
5135108	51351	NLA102S8	5621001	BDLL150S6256	177	
5135109	51351	NLA102S8	5621237	BDLL150S6411	177	
5135201	51352	NL102S9	5621122	BDLL150S6381	177	
5135202	51352	NL102S9	5621122	BDLL150S6381	202	
5135302	51353	NLA102S9	5621047	BDLL150S6302	177	
5135303	51353	NLA102S9	5621122	BDLL150S6381	177	
5135304	51353	NLA102S9	5621512	BDLL140S6471	177	
5135701	51357	NLA102S12	5620695	BDLL150S6054	177	
5135702	51357	NLA102S12	5620705	BDLL150S6064	177	
5135704	51357	NLA102S12	5621200	BDLL150S6387	177	
5135705	51357	NLA102S12	5621200	BDLL150S6387	207	
5135901	51359	NLA102S13	5621002	BDLL140S6258	151	
5135902	51359	NLA102S13	5620705	BDLL150S6064	175	
5135903	51359	NLA102S13	5621074	BDLL150S6318	177	
5136301	51363	NLA102S15	5620705	BDLL150S6064	177	
5136302	51363	NLA102S15	5621212	BDLL150S6397	162	
5136303	51363	NLA102S15	5620695	BDLL150S6054	177	
5136304	51363	NLA102S15	5621512	BDLL140S6471	177	
5136305	51363	NLA102S15	5621515	BDLL150S6474	177	
5136401	51364	NLA102S16	5620705	BDLL150S6064	177	
5136402	51364	NLA102S16	5621237	BDLL150S6411	177	
5203001	52030	BKBL47S5235	5621400	BDLL10S6454T	177	
5203101	52031	BKBL47S5235B	5621400	BDLL10S6454T	177	
5203301	52033	BKBL47S5391	5621400	BDLL10S6454T	187	
5203401	52034	BKBL47S5391B	5621400	BDLL10S6454T	212	
5203601	52036	BKBL47S5391C	5621803	BDLL10S6759CF	202	
5203701	52037	BKBL47S5391D	5621844	BDLL10S6797CF	244	
5203801	52038	CKBL40S5361B	5621544	BDLL150S6501	182	
5203802	52038	CKBL40S5361B	5621849	BDLL150S6802CF	212	
5204501	52045	BKBL52S548	5621205	BDLL10S6393	141	
5206001	52060	BKBL52S616	5620745	BDLL55S6093	126	
5206002	52060	BKBL52S616	5620775	BDLL55S6122	126	
5206401	52064	BKBL52S656	5620800	BDLL10S6134	151	
5206402	52064	BKBL52S656	5620930	BDLL10S6213	151	
5206403	52064	BKBL52S656	5621076	BDLL10S6319	136	
5206404	52064	BKBL52S656	5621099	BDLL15S6349	141	
5206406	52064	BKBL52S656	5621235	BDLL10S6410	151	
5206407	52064	BKBL52S656	5621236	BDLL10S6410A	151	
5206901	52069	BKBL97S5308	5621593	BDLL160S6550	177	
5208001	52080	BKBL52S5153	5621205	BDLL10S6393	157	
5208002	52080	BKBL52S5153	5621236	BDLL10S6410A	151	
5208004	52080	BKBL52S5153	5621236	BDLL10S6410A	173	
5208005	52080	BKBL52S5153	5621099	BDLL15S6349	151	
5208006	52080	BKBL52S5153	5621114	BDLL20S6370	177	
5208008	52080	BKBL52S5153	5621552	BDLL10S6509	131	
5208009	52080	BKBL52S5153	5621564	BDLL10S6521	185	
5208010	52080	BKBL52S5153	5621555	BDLL10S6512	173	
5209000	52090	BKBL54S5205	5621251	BDLL140S6422	173	
5209001	52090	BKBL54S5205	5621512	BDLL140S6471	177	

Injector Desp No.	Holder Desp No.	Holder Type Symbol No.	Nozzle Desp No.	Nozzle Type Symbol No.	Injector Working Pressure ( Bar )	Tab Code
5209002	52090	BKBL54S5205	5621615	BDLL140S6572	197	
5209003	52090	BKBL54S5205	5621656	BDLL140S6609	192	
5209004	52090	BKBL54S5205	5621655	BDLL140S6608	197	
5209005	52090	BKBL54S5205	5621657	BDLL140S6611	173	
5209006	52090	BKBL54S5205	5621669	BDLL140S6622	173	
5209008	52090	BKBL54S5205	5621670	BDLL140S6608A	192	
5209009	52090	BKBL54S5205	5621678	BDLL140S6630	173	
5209010	52090	BKBL54S5205	5621753	BDLL140S6707CF	188	
5209201	52092	BKBL54S5475	5621903	BDLL140S6852	190	
5209301	52093	BKBL54S5383	5621709	BDLL150S6662	203	FG
5209302	52093	BKBL54S5383	5621747	BDLL160S6700	197	
5209401	52094	BKBL54S5370	5621691	BDLL140S6644	173	
5209501	52095	BKBL54S5341	5621670	BDLL140S6608A	197	
5209502	52095	BKBL54S5341	5621656	BDLL140S6609	197	
5209601	52096	BKBL54S5312	5621600	BDLL150S6557	173	VH
5209602	52096	BKBL54S5312	5621616	BDLL150S6573	173	VJ
5209603	52096	BKBL54S5312	5621624	BDLL150S6580	203	VK
5209604	52096	BKBL54S5312	5621616	BDLL150S6573	202	
5209801	52098	BKBL60S5044	5621251	BDLL140S6422	178	
5209802	52098	BKBL60S5044	5621253	BDLL140S6423	187	
5209803	52098	BKBL60S5044	5621512	BDLL140S6471	177	
5209804	52098	BKBL60S5044	5621251	BDLL140S6422	187	
5209805	52098	BKBL60S5044	5620840	BDLL150S6159	167	
5209806	52098	BKBL60S5044	5621614	BDLL150S6571	175	
5209901	52099	BKBL54S5455	5621656	BDLL140S6609	264	
5210001	52100	BKBL54S5470	5621670	BDLL140S6608A	195	
5210002	52100	BKBL54S5470	5621753	BDLL140S6707CF	198	
5210101	52101	BKBL54S5471	5621670	BDLL140S6608A	195	
5210102	52101	BKBL54S5471	5621753	BDLL140S6707CF	188	
5210201	52102	BKBL54S5497	5621874	BDLL150S7919	198	
5210401	52104	CKBL60S5305	5620840	BDLL150S6159	187	
5210402	52104	CKBL60S5305	5621253	BDLL140S6423	187	
5210600	52106	BKBL60S5350	5621625	BDLL150S6582	168	
5210601	52106	BKBL60S5350	5621614	BDLL150S6571	168	
5210602	52106	BKBL60S5350	5621253	BDLL140S6423	168	
5210603	52106	BKBL60S5350	5620840	BDLL150S6159	165	
5210701	52107	CKBL62S5354	5621665	BDLL155S6619	192	
5210702	52107	CKBL62S5354	5621769	CDLL155S6722	192	
5210704	52107	CKBL62S5354	5621848	BDLL155S6801	192	
5210705	52107	CKBL62S5354	6801053	6801053	177	
5210901	52109	BKBL67S5269	5621120	BDLL150S6372	173	AV
5211201	52112	CKBL62S5419	5621769	CDLL155S6722	192	
5212801	52128	BKBL67S553	5620465	BDLL150S609	177	
5213600	52136	BKBL67S567	5620705	BDLL150S6064	177	
5213601	52136	BKBL67S567	5620620	BDLL150S685	177	
5213602	52136	BKBL67S567	6520680	BDLL150S6028	177	
5213603	52136	BKBL67S567	5621668	BDLL150S6621	177	
5214001	52140	BKBL67S596	5620465	BDLL150S609	177	
5215001	52150	BKBL67S650	5620770	BDLL140S6119	187	
5215002	52150	BKBL67S650	5620890	BDLL140S6192	187	
5215401	52154	BKBL67S668	5621810	BDLL150S6144	177	
5215402	52154	BKBL67S668	5620900	BDLL150S6194	177	
5215405	52154	BKBL67S668	5621065	BDLL150S6310	146	
5215408	52154	BKBL67S668	5621071	BDLL150S6315	177	
5215409	52154	BKBL67S668	5620722	BDLL150S6072B	175	

Injector Desp No.	Holder Desp No.	Holder Type Symbol No.	Nozzle Desp No.	Nozzle Type Symbol No.	Injector Working Pressure ( Bar )	Tab Code
5215410	52154	BKBL67S668	5621202	BDLL140S6388	177	
5215501	52155	BKBL67S668M	5620900	BDLL150S6194	177	
5216301	52163	BKBL67S5064	5620960	BDLL150S6225	172	
5216302	52163	BKBL67S5064	5621085	BDLL150S6329CF	172	
5216303	52163	BKBL67S5064	6521180	BDLL150S6385	202	
5216304	52163	BKBL67S5064	5621208	BDLL150S6395	172	
5216305	52163	BKBL67S5064	5620960	BDLL150S6225	177	
5216306	52163	BKBL67S5064	5621125	BDLL150S6382	177	
5216307	52163	BKBL67S5064	5621125	BDLL150S6382	177	
5216401	52164	BKBL67SD5064	5621097	BDLL150S6347	172	Z
5216402	52164	BKBL67SD5064	5621110	BDLL150S6355	172	Z
5216403	52164	BKBL67SD5064	5621120	BDLL150S6372	172	UB
5217001	52170	BKBL67S5100	5620960	BDLL150S6225	168	X
5217002	52170	BKBL67S5100	5621285	BDLL150S6435	168	AF
5217201	52172	BKBL67S5109	5620960	BDLL150S6225	172	X
5217401	52174	BKBL67S5151	5620960	BDLL150S6225	175	X
5217402	52174	BKBL67S5151	5621085	BDLL150S6329CF	168	Y
5217403	52174	BKBL67S5151	5621208	BDLL150S6395	168	ZZ
5217404	52174	BKBL67S5151	5621180	BDLL150S6385	177	W
5217405	52174	BKBL67S5151	5620960	BDLL150S6225	170	UA
5217406	52174	BKBL67S5151	5621181	BDLL150S6385A	198	W
5217407	52174	BKBL67S5151	5621125	BDLL150S6382	168	AC
5217408	52174	BKBL67S5151	5621285	BDLL150S6435	162	AB
5217409	52174	BKBL67S5151	5621208	BDLL150S6395	198	AD
5217410	52174	BKBL67S5151	5621285	BDLL150S6435	198	AJ
5217411	52174	BKBL67S5151	5621513	BDLL150S6472	168	AN
5217412	52174	BKBL67S5151	5621065	BDLL150S6310	162	BT
5217413	52174	BKBL67S5151	5621550	BDLL150S6507	168	BU
5217414	52174	BKBL67S5151	5621556	BDLL150S6513	162	CR
5217416	52174	BKBL67S5151	5621592	BDLL150S6549	172	CU
5217417	52174	BKBL67S5151	5621601	BDLL150S6558	162	DF
5217418	52174	BKBL67S5151	5621598	BDLL150S6555	168	CT
5217419	52174	BKBL67S5151	5621599	BDLL150S6556CF	168	CU
5217420	52174	BKBL67S5151	5621604	BDLL150S6561	168	DM
5217421	52174	BKBL67S5151	5621751	BDLL150S6705CF	168	FY
5217422	52174	BKBL67S5151	5621764	BDLL150S6713CF	162	GJ
5217423	52174	BKBL67S5151	5621777	BDLL150S6730CF	168	GL
5217501	52175	BKBL67SD5151	5621110	BDLL150S6355	173	Z
5217502	52175	BKBL67SD5151	5621120	BDLL150S6372	173	UB
5217503	52175	BKBL67SD5151	5621285	BDLL150S6435	177	
5217504	52175	BKBL67SD5151	5621513	BDLL150S6472	178	AK
5217505	52175	BKBL67SD5151	5621181	BDLL150S6385A	198	AL
5217506	52175	BKBL67SD5151	5621556	BDLL150S6513	178	BV
5217507	52175	BKBL67SD5151	5621597	BDLL150S6554	173	CS
5217508	52175	BKBL67SD5151	5621597	BDLL150S6554	173	CS
5217601	52176	BKBL67S5153	5620900	BDLL150S6194	177	2A
5217602	52176	BKBL67S5153	5621202	BDLL140S6388	177	2B
5217603	52176	BKBL67S5153	5621065	BDLL150S6310	137	2C
5217604	52176	BKBL67S5153	5621280	BDLL140S6433	168	2D
5217605	52176	BKBL67S5153	5621071	BDLL150S6315	177	2H
5217606	52176	BKBL67S5153	5621037	BDLL150S6292	177	2H
5217608	52176	BKBL67S5153	5621380	BDLL150S6452	162	2E
5217609	52176	BKBL67S5153	5621065	BDLL150S6310	168	2F
5217611	52176	BKBL67S5153	5620890	BDLL140S6192	177	
5217612	52176	BKBL67S5153	5621380	BDLL150S6452	177	2J

Injector Desp No.	Holder Desp No.	Holder Type Symbol No.	Nozzle Desp No.	Nozzle Type Symbol No.	Injector Working Pressure ( Bar )	Tab Code
5217613	52176	BKBL67S5153	5621517	BDLL150S6476	168	2K
5217614	52176	BKBL67S5153	5621626	BDLL140S6581	168	2L
5217615	52176	BKBL67S5153	5621625	BDLL150S6582	142	2M
5217616	52176	BKBL67S5153	5621625	BDLL150S6582	168	2N
5217618	52176	CKBL67S5153	5621764	BDLL150S6713CF	185	
5217624	52176	BKBL67S5153	5621804	BDLL150S6760CF	178	3B
5217625	52176	BKBL67S5153	5621810	BDLL150S6766CF	178	3C
5217626	52176	BKBL67S5153	5621810	BDLL150S6766CF	142	3D
5217627	52176	BKBL67S5153	5621811	BDLL150S6767CF	173	3E
5217629	52176	BKBL67S5153	5621862	BDLL150S6817CF	142	3H
5217701	52177	BKBL67S5153M	5621202	BDLL140S6388	177	
5217702	52177	BKBL67S5153M	5620900	BDLL150S6194	177	
5217800	52178	BKBL67S5172	5621646	BDLL150S6599	173	ED
5217801	52178	BKBL67S5172	5620960	BDLL150S6225	168	X
5217802	52178	BKBL67S5172	5621526	BDLL150S6486	168	AS
5218501	52185	BKBL67S5216	5621525	BDLL150S6484	172	
5218503	52185	BKBL67S5216	5621514	BDLL150S6473	177	CK
5218504	52185	BKBL67S5216	5621600	BDLL150S6557	172	CK
5219501	52195	BKBL67S5238	5621513	BDLL150S6472	192	AT
5219502	52195	BKBL67S5238	5621537	BDLL150S6494	197	AU
5219503	52195	BKBL67S5238	5621518	BDLL150S6472BC	207	BP
5219504	52195	BKBL67S5238	5621550	BDLL150S6507	172	BR
5219505	52195	BKBL67S5238	5621125	BDLL150S6382	177	BX
5219506	52195	BKBL67S5238	5621550	BDLL150S6507	197	CH
5219701	52197	BKBL67S5251	5621120	BDLL150S6372	172	
5219702	52197	BKBL67S5251	5621588	BDLL150S6545	172	
5219703	52197	BKBL67S5251	5621597	BDLL150S6554	172	
5219901	52199	BKBL76S5268	5621125	BDLL150S6382	172	
5219902	52199	BKBL67S5268	5621285	BDLL150S6435	172	
5219903	52199	BKBL67S5268	5621065	BDLL150S6310	172	
5219904	52199	BKBL67S5268	5621550	BDLL150S6507	172	
5219905	52199	BKBL67S5268	5621588	BDLL150S6545	172	
5219906	52199	BKBL67S5268	5621599	BDLL150S6556CF	172	
5219907	52199	BKBL67S5268	5621598	BDLL150S6555	172	
5219908	52199	BKBL67S5268	5621604	BDLL150S6561	172	
5219909	52199	BKBL67S5268	5621597	BDLL150S6554	172	
5220001	52200	BKBL72SD5241	5621530	BDLL18S6490	172	
5220002	52200	BKBL72SD5241	5621565	BDLL18S6522	178	
5220003	52200	BKBL72SD5241	5621566	BDLL18S6523	172	
5220301	52203	BKBL70SD5450	5621830	BDLL18S6787	192	
5220501	52205	BKBL72SD5273	5621530	BDLL18S6490	172	
5220502	52205	BKBL72SD5273	5621565	BDLL18S6522	192	
5220503	52205	BKBL72SD5273	5621566	BDLL18S6523	172	
5220601	52206	BKBL72SD5365	5621565	BDLL18S6522	192	
5220602	52206	BKBL72SD5365	5621686	BDLL18S6640	192	
5221101	52211	BKBL75S5292	5620695	BDLL150S6054	168	
5221102	52211	BKBL75S5292	5621212	BDLL150S6397	152	
5221103	52211	BKBL75S5292	5621668	BDLL150S6621	177	
5221104	52211	BKBL75S5292	5621662	BDLL150S6616	177	
5221501	52215	BKBL77S5010	5620995	BDLL130S6246	178	
5221502	52215	BKBL77S5010	5620996	BDLL140S6246	207	
5221503	52215	BKBL77S5010	5620996	BDLL140S6246	172	
5221504	52215	BKBL77S5010	5621105	BDLL160S6351	172	BR
5221505	52215	BKBL77S5010	5620997	BDLL160S6246	178	
5221506	52215	BKBL77S5010	5621225	BDLL160S6402	162	

Injector Desp No.	Holder Desp No.	Holder Type Symbol No.	Nozzle Desp No.	Nozzle Type Symbol No.	Injector Working Pressure ( Bar )	Tab Code
5221507	52215	BKBL77S5010S	5621225	BDLL160S6402	198	
5221508	52215	BKBL77S5010S	5620994	BDLL130S6246W	187	
5221509	52215	BKBL77S5010S	5620997	BDLL160S6246	187	
5221510	52215	BKBL77S5010S	5620996	BDLL140S6246	187	
5221511	52215	BKBL77S5010S	5620997	BDLL160S6246	188	
5221512	52215	BKBL77S5010S	5621227	BDLL150S6403	188	
5221601	52216	BKBL77S5374	5620997	BDLL160S6246	188	
5221701	52217	CKBL78S5420	5621645	CDLL160S6598	190	
5221801	52218	CKBL78S5284	5621559	BDLL160S6516	182	
5221802	52218	CKBL78S5284	5621645	CDLL160S6598	192	
5221803	52218	CKBL78S5284	5621871	BDLL160S6830	192	
5221804	52218	CKBL78S5284	6801078	6801078	177	
5221902	52219	BKBL80S5388	5621713	BDLL150S6666	185	
5221903	52219	BKBL80S5388	5621712	BDLL150S6665	185	
5221904	52219	BKBL80S5388	5621807	BDLL150S6764	183	
5221906	52219	BKBL80S5388	5621813	BDLL150S6770CF	183	
5221909	52219	BKBL80S5388	5621821	BDLL150S6774CF	185	
5221910	52219	BKBL80S5388	5621837	BDLL150S6790CF	185	
5221911	52219	BKBL80S5388	5621251	BDLL140S6422	178	
5221912	52219	BKBL80S5388	5621614	BDLL150S6571	178	
5221913	52219	BKBL80S5388	5621330	BDLL150S6443	178	
5221914	52219	BKBL80S5388	5621517	BDLL150S6476	178	
5221915	52219	BKBL80S5388	5621859	BDLL150S6813CF	187	
5221916	52219	BKBL80S5388	5621860	BDLL150S6814CF	182	
5221917	52219	BKBL80S5388	5621827	BDLL150S6780CF	185	
5221918	52219	BKBL80S5388	5621869	BDLL150S6828CF	185	
5221919	52219	BKBL80S5388	5621870	BDLL150S6829CF	185	
5222001	52220	BKBL80S5389	5621085	BDLL150S6329CF	197	
5222002	52220	BKBL80S5389	5621714	BDLL150S6667	211	
5222003	52220	BKBL80S5389	5621745	BDLL150S6698	211	
5222004	52220	BKBL80S5389	5621595	BDLL150S6552	211	
5222007	52220	BKBL80S5389	5621828	BDLL150S6781CF	211	
5222008	52220	BKBL80S5389	5621837	BDLL150S6790CF	211	
5222100	52221	BKBL80S5204	5621330	BDLL150S6443	178	
5222102	52221	BKBL80S5204	5621517	BDLL150S6476	178	
5222103	52221	BKBL80S5204	5621251	BDLL140S6422	178	
5222105	52221	BKBL80S5204	5621407	BDLL150S6457	188	
5222106	52221	BKBL80S5204	5621572	BDLL150S6529	182	
5222107	52221	BKBL80S5204	5621614	BDLL150S6571	178	
5222108	52221	BKBL80S5204	5621251	BDLL140S6422	178	
5222201	52222	BKBL80S5377	5621085	BDLL150S6329CF	202	
5222202	52222	BKBL80S5377	5621208	BDLL150S6395	207	
5222203	52222	BKBL80S5377	5621285	BDLL150S6435	202	
5222301	52223	BKBL80S5437	5621712	BDLL150S6665	178	
5222303	52223	BKBL80S5437	5620405	BDLL150S559	192	
5222304	52223	BKBL80S5437	5621821	BDLL150S6774CF	185	
5222305	52223	BKBL80S5437	5621827	BDLL150S6780CF	185	
5222307	52223	BKBL80S5437	5621837	BDLL150S6790CF	185	
5222308	52223	BKBL80S5437	5621870	BDLL150S6829CF	185	
5222309	52223	BKBL80S5437	5621869	BDLL150S6828CF	185	
5222310	52223	BKBL80S5437	5621712	BDLL150S6665	183	
5222401	52224	BKBL80S5309	5621595	BDLL150S6552	183	
5222402	52224	BKBL80S5309	5621260	BDLL150S6429	207	
5222403	52224	BKBL80S5309	5621285	BDLL150S6435	207	
5222404	52224	BKBL80S5309	5621208	BDLL150S6395	207	

Injector Desp No.	Holder Desp No.	Holder Type Symbol No.	Nozzle Desp No.	Nozzle Type Symbol No.	Injector Working Pressure ( Bar )	Tab Code
5222701	52227	BKBL80S5449	5621826	BDLL150S6779CF	211	ET
5222702	52227	BKBL80S5449	5621595	BDLL150S6552	211	
5222703	52227	BKBL80S5449	5621745	BDLL150S6698	211	
5222901	52229	BKBL80S5482	5621828	BDLL150S6781CF	211	
5222902	52229	BKBL80S5482	5621837	BDLL150S6790CF	211	
5223101	52231	CKBL86S5433	5621610	BDLL160S6567	190	
5223102	52231	CKBL86S5433	5621645	CDLL160S6598	192	
5223103	52231	CKBL86S5433	5621559	BDLL160S6516	182	
5223104	52231	CKBL86S5433	5621871	BDLL160S6830	192	
5223601	52236	BKBL82S5399	5621739	BDLL145S6692	202	
5223602	52236	BKBL82S5399	5621740	BDLL145S6693	202	
5223603	52236	BKBL82S5399	5621741	BDLL145S6694	202	
5223701	52237	CKBL88SD5458B	5621544	BDLL150S6501	186	
5223801	52238	CKBL88SD5459B	5621849	BDLL150S6802CF	217	
5223802	52238	CKBL88SD5459B	5621544	BDLL150S6501	187	
5223805	52238	CKBL88SD5459B	5621789	BDLL150S6741CF	182	
5224402	52244	BKBL87S664	5620845	BDLL120S6163	172	
5224406	52244	BKBL87S664	5620935	BDLL140S6214	172	
5224603	52246	BKBL87S5133	5620845	BDLL120S6163	172	
5225002	52250	BKBL87S5153	5621535	BDLL160S6492	177	
5225003	52250	BKBL87S5153	5621562	BDLL160S6519	177	
5225101	52251	CKBL88S5436	5621603	BDLL160S6560	202	
5225201	52252	BKBL88S5453	5621789	BDLL150S6741CF	220	
5225202	52252	BKBL88S5453	5621723	BDLL150S6676	220	
5225203	52252	BKBL88S5453	5621544	BDLL150S6501	180	
5225204	52252	BKBL88S5453	5621585	BDLL150S6542	182	
5225205	52252	BKBL88S5453	5621723	BDLL150S6676	180	
5225206	52252	BKBL88S5453	5621789	BDLL150S6741CF	180	
5225401	52254	BKBL87S5189	5621535	BDLL160S6492	168	
5225402	52254	BKBL87S5189	5621562	BDLL160S6519	168	
5225403	52254	BKBL87S5189	5621629	BDLL160S6585	168	
5225405	52254	BKBL87S5189	5621710	BDLL160S6663	192	
5225406	52254	BKBL87S5189	5621719	BDLL160S6672	197	
5225407	52254	BKBL87S5189	5621749	BDLL160S6701	168	
5225408	52254	BKBL87S5189	5621750	BDLL160S6702	192	
5225701	52257	BKBL87S5271B	5620845	BDLL120S6163	172	
5225802	52258	BKBL87S5349	5621594	BDLL160S6551	177	
5225803	52258	BKBL87S5349	5621535	BDLL160S6492	175	
5226001	52260	RKBL88SD5234	5620960	BDLL150S6225	177	
5226002	52260	RKBL88SD5234	5621547	BDLL150S6504	177	
5226101	52261	BKBL88S5424	5621788	BDLL145S6739	184	
5226201	52262	RKBL88S5270	5621544	BDLL150S6501	177	
5226202	52262	RKBL88S5270	5621585	BDLL150S6542	177	
5226203	52262	RKBL88S5270	5621723	BDLL150S6676	177	
5226204	52262	RKBL88S5270	5621789	BDLL150S6741CF	177	
5226301	52263	BKBL91SY5252	5621529	BDLL160S6488	212	
5226401	52264	BKBL90S5214	5620916	BDLL140S6205A	158	
5226402	52264	BKBL90S5214	5620895	BDLL140S6193	163	
5226501	52265	BKBL95S5021	5621036	BDLL150S6288A	151	
5226502	52265	BKBL95S5021	5621036	BDLL150S6288A	192	
5226503	52265	BKBL95S5021	5621033	BDLL160S6283	172	
5226601	52266	BKBL95S5021B	5620655	BDLL140S6001	142	
5226602	52266	BKBL95S5021B	5621029	BDLL140S6281	140	
5226603	52266	BKBL95S5021B	5621033	BDLL160S6283	173	
5226607	52266	BKBL95S5021B	5621036	BDLL150S6288A	142	

Injector Desp No.	Holder Desp No.	Holder Type Symbol No.	Nozzle Desp No.	Nozzle Type Symbol No.	Injector Working Pressure ( Bar )	Tab Code
5226608	52266	BKBL95S5021B	5621036	BDLL150S6288A	182	A
5226610	52266	BKBL95S5021B	5621036	BDLL150S6288A	172	
5226801	52268	BKBL90S5333	5621554	BDLL150S6511	202	
5226901	52269	BKBL90S5214A	5620916	BDLL140S6205A	152	
5227001	52270	BKBL90S5356	5620916	BDLL140S6205A	160	
5227101	52271	BKBL90S5214L	5620916	BDLL140S6205A	165	
5227501	52275	RKBL95SD5352	5621651	BDLL22S6604	182	
5227601	52276	RKBL95S5444	5621744	BDLL27S6697	177	
5228301	52283	BKBL96S684	5620790	BDLL150S6130A	182	
5228302	52283	BKBL96S684	5620835	BDLL150S6156	197	
5228401	52284	BKBL96S684M	5620790	BDLL150S6130A	182	B
5228402	52284	BKBL96S684M	5620835	BDLL150S6156	182	
5228501	52285	BKBL96S684MA	5620790	BDLL150S6130A	182	
5228502	52285	BKBL96S684MA	5620835	BDLL150S6156	182	
5229001	52290	BKBL96SY5138M	5620790	BDLL150S6130A	243	
5229101	52291	BKBL96S5138	5620835	BDLL150S6156	243	
5229102	52291	BKBL96S5138	5620790	BDLL150S6130A	243	
5230001	52300	BKBL96S5250	5620835	BDLL150S6156	238	
5230002	52300	BKBL96S5250	5620790	BDLL150S6130A	238	
5230003	52300	BKBL96S5250	5620705	BDLL150S6064	238	C
5230004	52300	BKBL96S5250	5620790	BDLL150S6130A	173	
5230005	52300	BKBL96S5250	5620835	BDLL150S6156	173	
5230007	52300	BKBL96S5250	5621639	BDLL150S6594	238	
5230008	52300	BKBL96S5250	5621654	BDLL150S6607	238	
5230301	52303	BKBL96S5348	5620705	BDLL150S6064	218	
5230302	52303	BKBL96S5348	5621654	BDLL150S6607	218	
5230303	52303	BKBL96S5348	5621687	BDLL150S6641	218	
5230304	52303	BKBL96S5348	5621737	BDLL150S6690	218	
5230305	52303	BKBL96S5348	5621738	BDLL150S6691	218	F
5230306	52303	BKBL96S5348	5621737	BDLL150S6690	173	
5230307	52303	BKBL96S5348	5621868	BDLL150S6826CF	218	
5230308	52303	BKBL96S5348	5621918	BDLL150S6854CF	223	
5230601	52306	BKBL96S5351	5620835	BDLL150S6156	238	
5230602	52306	BKBL96S5351	5621634	BDLL150S6589	238	
5230603	52306	BKBL96S5351	5620835	BDLL150S6156	238	
5230604	52306	BKBL96S5351	5621662	BDLL150S6616	238	
5230605	52306	BKBL96S5351	5621661	BDLL150S6615	238	
5230606	52306	BKBL96S5351	5621663	BDLL150S6617	188	H
5230607	52306	BKBL96S5351	5621661	BDLL150S6615	238	
5231001	52310	BKBL97S55	5620795	BDLL40S6131	177	
5231002	52310	BKBL97S55	5620965	BDLL80S6228	177	
5231003	52310	BKBL97S55	5621018	BDLL80S6273	177	
5231004	52310	BKBL97S55	5620680	BDLL150S6028	168	
5231005	52310	BKBL97S55	5620705	BDLL150S6064	177	
5231006	52310	BKBL97S55	5620405	BDLL150S559	168	
5231007	52310	BKBL97S55	5620855	BDLL160S6173	151	
5231301	52313	BKBL97S5334	5621648	BDLL150S6601	177	J
5231302	52313	BKBL97S5334	5621648	BDLL150S6601	203	
5231303	52313	BKBL97S5334	5621648	BDLL150S6601	168	
5231304	52313	BKBL97S5334	5621782	BDLL150S6736	203	
5231305	52313	BKBL97S5334	5621855	BDLL150S6808CF	203	
5231306	52313	BKBL97S5334	5621873	BDLL150S6833CF	213	
5231801	52318	BKBL97S66B	5620705	BDLL150S6064	177	
5233201	52332	BKBL97SD78	5620680	BDLL150S6028	177	
5235101	52351	BKBL97SD501	5620645	BDLL120S694	177	

Injector Desp No.	Holder Desp No.	Holder Type Symbol No.	Nozzle Desp No.	Nozzle Type Symbol No.	Injector Working Pressure ( Bar )	Tab Code
5236201	52362	BKBL97SD518	5620645	BDLL120S694	177	
5237001	52370	BKBL97S548	5620960	BDLL150S6225	177	
5238101	52381	BKBL97SD567	5620680	BDLL150S6028	170	
5238401	52384	BKBL97S577	5620940	BDLL150S6218	177	
5238402	52384	BKBL97S577	5620405	BDLL150S559	177	
5238403	52384	BKBL97S577	5620680	BDLL150S6028	177	
5238404	52384	BKBL97S577	5620705	BDLL150S6064	177	
5238405	52384	BKBL97S577	5621039	BDLL150S6295	177	
5240201	52402	BKBL97S602B	5621710	BDLL150S6065	177	
5240202	52402	BKBL97S602B	5620805	BDLL150S6138	177	
5240203	52402	BKBL97S602B	5621023	BDLL150S6275	177	
5240204	52402	BKBL97S602B	5621023	BDLL150S6275	182	
5241401	52414	BKBL97S623	5620465	BDLL150S609	177	
5242201	52422	BKBL97S632M	5620790	BDLL150S6130A	182	
5242601	52426	BKBL97S638	5620645	BDLL120S694	177	
5242602	52426	BKBL97S638	5621010	BDLL140S6268	177	
5243001	52430	BKBL97S650	5620770	BDLL140S6119	187	
5243002	52430	BKBL97S650	5620890	BDLL140S6192	187	
5243401	52434	BKBL97S661B	5620621	BDLL150S685S	177	
5243402	52434	BKBL97S661B	5620755	BDLL150S6097S	136	
5243403	52434	BKBL97S661B	5620720	BDLL150S6072	136	
5243404	52434	BKBL97S661B	5620721	BDLL150S6072A	177	
5243405	52434	BKBL97S661B	5620722	BDLL150S6072B	187	
5243408	52434	BKBL97S661B	5621227	BDLL150S6403	136	
5243410	52434	BKBL97S661B	5792069	BDLL150SX5052	202	
5243411	52434	BKBL97S661B	5621290	BDLL150S6438	202	
5243801	52438	BKBL97S668	5620815	BDLL90S6147	182	
5243803	52438	BKBL97S668	5620960	BDLL150S6225	177	
5243901	52439	BKBL97S668M	5620770	BDLL140S6119	187	
5243902	52439	BKBL97S668M	5620890	BDLL140S6192	187	
5244401	52444	BKBL97S673	5620855	BDLL160S6173	177	
5246401	52464	BKBL97S5002	5620890	BDLL140S6192	187	
5246402	52464	BKBL97S5002	5621025	BDLL140S6276	187	
5246405	52464	BKBL97S5002	5621103	BDLL140S6350	187	
5246601	52466	BKBL97S5006	5621057	BDLL140S6306	168	
5246602	52466	BKBL97S5006	5620895	BDLL140S6193	157	
5246603	52466	BKBL97S5006	5620915	BDLL140S6205	157	
5246604	52466	BKBL97S5006	5621029	BDLL140S6281	157	
5246605	52466	BKBL97S5006	5620916	BDLL140S6205A	168	
5246606	52466	BKBL97S5006	5621052	BDLL140S6304	178	
5246607	52466	BKBL97S5006	5621057	BDLL140S6306	168	
5246608	52466	BKBL97S5006	5620916	BDLL140S6205A	182	
5246801	52468	BKBL97S5006B	5620895	BDLL140S6193	157	
5246802	52468	BKBL97S5006B	5621029	BDLL140S6281	167	
5246803	52468	BKBL97S5006B	5621057	BDLL140S6306	168	
5246804	52468	BKBL97S5006B	5621029	BDLL140S6281	158	
5246805	52468	BKBL97S5006B	5620915	BDLL140S6205	158	
5246806	52468	BKBL97S5006B	5620916	BDLL140S6205A	168	
5247801	52478	BKBL97S5024	5620960	BDLL150S6225	177	
5248501	52485	BKBL97S5039	5620940	BDLL150S6218	177	
5248502	52485	BKBL97S5039	5620680	BDLL150S6028	177	
5249101	52491	BKBL97S5048	5620855	BDLL160S6173	177	
5249102	52491	BKBL97S5048	5620720	BDLL150S6072	177	
5249103	52491	BKBL97S5048	5620722	BDLL150S6072B	177	
5249701	52497	BKBL97S5053B	5620998	BDLL150S6253	172	

Injector Desp No.	Holder Desp No.	Holder Type Symbol No.	Nozzle Desp No.	Nozzle Type Symbol No.	Injector Working Pressure ( Bar )	Tab Code
5250801	52508	BKBL97S5064	5620960	BDLL150S6225	172	X
5251201	52512	BKBL97S5078B	5620998	BDLL150S6253	172	
5251202	52512	BKBL97S5078B	5621072	BDLL150S6317	162	
5251203	52512	BKBL97S5078B	5620998	BDLL150S6253	207	
5251701	52517	BKBL97S5089	5621025	BDLL140S6276	177	
5251702	52517	BKBL97S5089	5620890	BDLL140S6192	162	
5251703	52517	BKBL97S5089	5620890	BDLL140S6192	172	
5252301	52523	BKBL97S5117	5621103	BDLL140S6350	187	
5252603	52526	BKBL97S5122B	5621055	BDLL150SX4652	177	
5252604	52526	BKBL97S5122B	5621249	BDLL150S6421	177	
5252605	52526	BKBL97S5122B	5621260	BDLL150S6429	177	
5252901	52529	BKBL97S5149	5621210	BDLL28.5S6396	177	
5252902	52529	BKBL97S5149	5621210	BDLL28.5S6396	227	
5253201	52532	BKBL97S5150	5620855	BDLL160S6173	168	
5253202	52532	BKBL97S5150	5620860	BDLL150S6176	136	
5253204	52532	BKBL97S5150	5620722	BDLL150S6072B	177	
5253205	52532	BKBL97S5150	5620856	BDLL170S6173	168	
5253206	52532	BKBL97S5150	5621330	BDLL150S6443	177	
5253207	52532	BKBL97S5150	5621206	BDLL160S6394	177	
5253208	52532	BKBL97S5150	5621330	BDLL150S6443	182	
5253209	52532	BKBL97S5150	5621667	BDLL160S6584T	168	
5253501	52535	BKBL97S5151	5620960	BDLL150S6225	168	X
5253502	52535	BKBL97S5151	5620815	BDLL90S6147	182	
5253701	52537	CKB40S5320	5650091	RDN0SPC6209	140	
5253801	52538	BKBL97S5152	5621025	BDLL140S6276	168	
5253802	52538	BKBL97S5152	5620890	BDLL140S6192	172	
5253803	52538	BKBL97S5152	5621245	BDLL140S6417	168	
5253804	52538	BKBL97S5152	5621335	BDLL140S6445	177	
5253805	52538	BKBL97S5152	5621405	BDLL140S6455	168	
5253806	52538	BKBL97S5152	5621637	BDLL140S6592	178	
5253807	52538	BKBL97S5152	5621748	BDLL140S6592F	188	
5254100	52541	BKBL97S5153	5621025	BDLL140S6276	187	
5254101	52541	BKBL97S5153	5621103	BDLL140S6350	187	
5254102	52541	BKBL97S5153	5621206	BDLL160S6394	168	
5254103	52541	BKBL97S5153	5620890	BDLL140S6192	177	
5254104	52541	BKBL97S5153	5620855	BDLL160S6173	168	
5254105	52541	BKBL97S5153	5620770	BDLL140S6119	187	
5254106	52541	BKBL97S5153	5621010	BDLL140S6268	177	
5254107	52541	BKBL97S5153	5620745	BDLL55S6093	151	
5254108	52541	BKBL97S5153	5621251	BDLL140S6422	187	
5254109	52541	BKBL97S5153	5621522	BDLL140S6481	177	
5254110	52541	BKBL97S5153	5621330	BDLL150S6443	187	
5254111	52541	BKBL97S5153	5621545	BDLL150S6502	168	
5254112	52541	BKBL97S5153	5621549	BDLL150S6506	168	
5254113	52541	BKBL97S5153	5621551	BDLL150S6508	168	
5254114	52541	BKBL97S5153	5621517	BDLL150S6476	168	
5254115	52541	BKBL97S5153	5621330	BDLL150S6443	177	
5254116	52541	BKBL97S5153	5621330	BDLL150S6443	192	
5254117	52541	BKBL97S5153	5621628	BDLL160S6584	192	
5254118	52541	BKBL97S5153	5621650	BDLL150S6603	192	
5254119	52541	BKBL97S5153	5621659	BDLL150S6613	192	
5254120	52541	BKBL97S5153	5621628	BDLL160S6584	168	
5254121	52541	BKBL97S5153	5621206	BDLL160S6394	192	
5254122	52541	BKBL97S5153	5621549	BDLL150S6506	192	
5254124	52541	BKBL97S5153	5621684	BDLL150S6638	182	

Injector Desp No.	Holder Desp No.	Holder Type Symbol No.	Nozzle Desp No.	Nozzle Type Symbol No.	Injector Working Pressure ( Bar )	Tab Code
5254125	52541	BKBL97S5153	5621743	BDLL160S6696	192	EU
5254126	52541	BKBL97S5153	5621752	BDLL150S6706	208	
5254127	52541	BKBL97S5153	5621756	BDLL160S6703CF	168	
5254128	52541	BKBL97S5153	5621797	BDLL160S6750CF	203	
5254129	52541	BKBL97S5153	5621637	BDLL140S6592	175	
5254131	52541	BKBL97S5153	5621798	BDLL160S6752CF	203	
5254132	52541	BKBL97S5153	5621822	BDLL160S6775CF	203	
5254133	52541	BKBL97S5153	5621888	BDLL150S6838CF	168	
5254501	52545	BKBL97S5154B	5620710	BDLL150S6065	177	
5254502	52545	BKBL97S5154B	5620805	BDLL150S6138	177	
5254503	52545	BKBL97S5154B	5621023	BDLL150S6275	121	
5255501	52555	BKBL97S5189	5621549	BDLL150S6506	192	
5255502	52555	BKBL97S5189	5621517	BDLL150S6476	192	
5258001	52580	BKBL97S5213	5620710	BDLL150S6065	177	
5258002	52580	BKBL97S5213	5620805	BDLL150S6138	177	
5258003	52580	BKBL97S5213	5621023	BDLL150S6275	177	
5259001	52590	CKBL97S5242	5620695	BDLL150S6054	175	
5259301	52593	BKBL97S5275B	5620755	BDLL150S6097S	136	
5259302	52593	BKBL97S5275B	5621227	BDLL150S6403	132	
5259303	52593	BKBL97S5275B	5621290	BDLL150S6438	198	
5259304	52593	BKBL97S5275B	5620722	BDLL150S6072B	173	
5259801	52598	BKBL97S5282	5621210	BDLL28.5S6396	218	
5259802	52598	BKBL97S5282	5621210	BDLL28.5S6396	168	
5260001	52600	BKBL97S5285	5620710	BDLL150S6065	177	
5260002	52600	BKBL97S5285	5620805	BDLL150S6138	168	
5260003	52600	BKBL97S5285	5621023	BDLL150S6275	168	
5260301	52603	BKBL97S5338	5620790	BDLL150S6130A	188	
5260302	52603	BKBL97S5338	5621260	BDLL150S6429	188	
5260303	52603	BKBL97S5338	5620855	BDLL160S6173	177	
5260304	52603	BKBL97S5338	5620680	BDLL150S6028	167	
5260305	52603	BKBL97S5338	5621668	BDLL150S6621	188	
5260306	52603	BKBL97S5338	5621662	BDLL150S6616	177	
5260307	52603	BKBL97S5338	5621085	BDLL150S6329CF	192	
5260308	52603	BKBL97S5338	5620722	BDLL150S6072B	188	
5260501	52605	BKBL97S5289	5620680	BDLL150S6028	177	
5260601	52606	BKBL97S5299	5621630	BDLL150S6586	203	
5260602	52606	BKBL97S5299	5621659	BDLL150S6613	203	
5260604	52606	BKBL97S5299	5621588	BDLL150S6545	212	
5260606	52606	BKBL97S5299	5621652	BDLL150S6605	203	
5260607	52606	BKBL97S5299	5621802	BDLL160S6758CF	222	
5260608	52606	bKBL97S5299	5621850	VDLL150S6803	192	
5260609	52606	BKBL97S5299	5621853	BDLL150S6806CF	202	
5260610	52606	BKBL97S5299	5621854	BDLL155S6807CF	202	
5260611	52606	BKBL97S5299	5621877	VDLL150S6837CF	192	BEZ
5260612	52606	BKBL97S5299	5621889	VDLL150S6839CF	192	BEY
5260701	52607	BKBL97S5300	5621010	BDLL140S6268	177	
5260801	52608	BKBL97S5340B	5621290	BDLL150S6438	192	
5260901	52609	BKBL97S5308	5621593	BDLL160S6550	177	
5260902	52609	BKBL97S5308	5621607	BDLL160S6564	177	
5260903	52609	BKBL97S5308	5621612	BDLL160S6569	172	
5261001	52610	BKBL97S5326	5621612	BDLL160S6569	177	
5261002	52610	BKBL97S5326	5621593	BDLL160S6550	177	
5261003	52610	BKBL97S5326	5621607	BDLL160S6564	177	
5261101	52611	BKBL100S557	5620875	BDLL110S6186	151	
5261301	52613	BKBL98S5330	5621593	BDLL160S6550	177	

Injector Desp No.	Holder Desp No.	Holder Type Symbol No.	Nozzle Desp No.	Nozzle Type Symbol No.	Injector Working Pressure ( Bar )	Tab Code
5261302	52613	BKBL98S5330	5621607	BDLL160S6564	177	
5261303	52613	BKBL98S5330	5621612	BDLL160S6569	212	
5261306	52613	BKBL98S5330	5621672	BDLL160S6624	217	
5261307	52613	BKBL98S5330	5621671	BDLL160S6623	217	
5261601	52616	BKBL100S5037S	5620990	BDLL150S6244	177	
5261602	52616	BKBL100S5037S	5620991	BDLL150S6244W	177	
5261901	52619	BKBL100S5231B	5621407	BDLL150S6457	168	
5261902	52619	BKBL100S5231B	5621231	BDLL150S6408	127	
5261903	52619	BKBL100S5231B	5621290	BDLL150S6438	142	
5261904	52619	BKBL100S5231B	5620780	BDLL150S6123	136	
5261905	52619	BKBL100S5231B	5621229	BDLL150S6407	127	
5261906	52619	BKBL100S5231B	5620860	BDLL150S6176	136	
5262401	52624	BKBL100S5367B	5621664	BDLL150S6618	202	
5262501	52625	BKBL100SD5289	5620680	BDLL150S6028	177	
5262701	52627	BKBL100S5296	5620705	BDLL150S6064	177	
5262702	52627	BKBL100S5296	5620741	BDLL135S6092	162	
5262703	52627	BKBL100S5296	5620785	BDLL135S6124	172	
5262704	52627	BKBL100S5296	5621050	BDLL135S6303	162	
5262705	52627	BKBL100S5296	5620680	BDLL150S6028	177	
5262706	52627	BKBL100S5296	5620740	HL135SC247	172	
5262901	52629	BKBL100S5318B	5621606	BDLL150S6563	147	
5262902	52629	BKBL100S5318B	5621407	BDLL150S6457	168	
5262903	52629	BKBL100S5318B	5621290	BDLL150S6438	192	
5262904	52629	BKBL100S5318B	5621606	BDLL150S6563	192	
5262905	52629	BKBL100S5318B	5621664	BDLL150S6618	192	
5262906	52629	BKBL100S5318B	5621664	BDLL150S6618	202	
5263001	52630	BKBL102S562	5620680	BDLL150S6028	177	
5263002	52630	BKBL102S562	5620705	BDLL150S6064	177	
5263003	52630	BKBL102S562	5620741	BDLL135S6092	172	
5263004	52630	BKBL102S562	5620785	BDLL135S6124	177	
5263005	52630	BKBL102S562	5621050	BDLL135S6303	177	
5263006	52630	BKBL102S562	5621050	BDLL135S6303	172	
5263801	52638	BKBL102S617	5620780	BDLL150S6123	136	
5263802	52638	BKBL102S617	5620860	BDLL150S6176	136	
5263803	52638	BKBL102S617	5621059	BDLL150S6307	136	
5263804	52638	BKBL102S617	5621095	BDLL150S6342	136	
5263805	52638	BKBL102S617	5620755	BDLL150S6097S	136	
5263806	52638	BKBL102S617	5621095	BDLL150S6342	136	
5263807	52638	BKBL102S617	5621096	BDLL150S6342A	136	
5263808	52638	BKBL102S617	5621229	BDLL150S6407	136	
5263809	52638	BKBL102S617	5621231	BDLL150S6408	136	
5263810	52638	BKBL102S617	5620405	BDLL150S559	162	
5263811	52638	BKBL102S617	5621290	BDLL150S6438	157	
5263812	52638	BKBL102S617	5621407	BDLL150S6457	136	
5264201	52642	BKBL102S5231B	5621407	BDLL150S6457	136	
5264202	52642	BKBL102S5231B	5621231	BDLL150S6408	136	
5264301	52643	BKBL102S5411	5621689	BDLL140S6627	248	
5264302	52643	BKBL102S5411	5621759	BDLL150S6712	223	
5264601	52646	BKBL102S5323A	5621618	BDLL150S6575	198	
5264602	52646	BKBL102S5323A	5621618	BDLL150S6575	218	
5264603	52646	BKBL102S5323A	5621617	BDLL140S6574	173	
5264604	52646	BKBL102S5323A	5621617	BDLL140S6574	213	
5264700	52647	BKBL102S5323	5621618	BDLL150S6575	218	
5264701	52647	BKBL102S5323	5621618	BDLL150S6575	168	
5264702	52647	BKBL102S5323	5621617	BDLL140S6574	168	

Injector Desp No.	Holder Desp No.	Holder Type Symbol No.	Nozzle Desp No.	Nozzle Type Symbol No.	Injector Working Pressure ( Bar )	Tab Code
5264705	52647	BKBL102S5323	5621618	BDLL150S6575	198	
5264801	52648	BKBL102S5395	5621689	BDLL140S6627	254	
5264802	52648	BKBL102S5395	5621538	BDLL150S6495	223	
5265701	52657	BKBL103S5380	5621716	BDLL150S6669	188	
5265801	52658	BKBL105S5325A	5621511	BDLL150S6471	192	
5265802	52658	BKBL105S5325A	5621538	BDLL150S6495	218	
5265803	52658	BKBL105S5325A	5621746	BDLL150S6699	238	
5265902	52659	BKBL105S5334	5621876	BDLL140S6835	178	
5266001	52660	BKBL105S5104	5621098	BDLL150S6348	177	
5266201	52662	BKBL105S5360A	5621538	BDLL150S6495	218	
5266202	52662	BKBL105S5360A	5621675	BDLL150S6627	218	
5266301	52663	BKBL150S5369	5621689	BDLL140S6627	208	
5266302	52663	BKBL150S5369	5621689	BDLL140S6627	254	
5266401	52664	BKBL105S5130	5621098	BDLL150S6348	177	
5266501	52665	BKBL105S5294	5620705	BDLL150S6064	168	
5266502	52665	BKBL105S5294	5620695	BDLL150S6054	168	
5266503	52665	BKBL105S5294	5621074	BDLL150S6318	168	
5266504	52665	BKBL105S5294	5621237	BDLL150S6411	177	
5266505	52665	BKBL105S5294	5620680	BDLL150S6028	168	
5266506	52665	BKBL105S5294	5621085	BDLL150S6329CF	177	
5266507	52665	BKBL105S5294	5621001	BDLL150S6256	177	
5266508	52665	BKBL105S5294	5621668	BDLL150S6621	177	
5266509	52665	BKBL105S5294	5620835	BDLL150S6156	177	
5266510	52665	BKBL105S5294	5620925	BDLL150S6211	177	
5266601	52666	BKBL105S5295	5621237	BDLL150S6411	177	
5266801	52668	BKBL105S5325	5621511	BDLL150S6471	192	
5266802	52668	BKBL105S5325	5621538	BDLL150S6495	202	
5266803	52668	BKBL105S5325	5621746	BDLL150S6699	243	
5266901	52669	BKBL105S5360	5621538	BDLL150S6495	222	
5266902	52669	BKBL105S5360	5621675	BDLL150S6627	222	
5267100	52671	BKBL105S5203	5621098	BDLL150S6348	238	
5267201	52672	BKBL105S5208	5621098	BDLL150S6348	238	
5267301	52673	BKBL105S5292	5620705	BDLL150S6064	168	
5267302	52673	BKBL105S5292	5621212	BDLL150S6397	152	
5267303	52673	BKBL105S5292	5620695	BDLL150S6054	168	
5267304	52673	BKBL105S5292	5621512	BDLL140S6471	168	
5267305	52673	BKBL105S5292	5621515	BDLL150S6474	168	
5267306	52673	BKBL105S5292	5621251	BDLL140S6422	168	
5267307	52673	BKBL105S5292	5621668	BDLL150S6621	168	
5267308	52673	BKBL105S5292	5621678	BDLL140S6630	168	
5267401	52674	BKBL105S5293	5621002	BDLL140S6258	168	
5267402	52674	BKBL105S5293	5620705	BDLL150S6064	168	
5267403	52674	BKBL105S5293	5621074	BDLL150S6318	168	
5267405	52674	BKBL105S5293	5621538	BDLL150S6495	168	
5267406	52674	BKBL105S5293	5621675	BDLL150S6627	177	
5267407	52674	BKBL105S5293	5621653	BDLL140S6606	173	
5267501	52675	BKBL108S5192	5621260	BDLL150S6429	168	
5267502	52675	BKBL108S5192	5621050	BDLL135S6303	173	
5267503	52675	BKBL108S5192	5621345	BDLL150S6448	238	
5267801	52678	BKBL108S5297	5621345	BDLL150S6448	207	
5267802	52678	BKBL108S5297	5621050	BDLL135S6303	203	
5267803	52678	BKBL108S5297	5621260	BDLL150S6429	177	
5267901	52679	BKBL108S5392	5621717	BDLL150S6670	168	
5267902	52679	BKBL108S5392	5621718	BDLL150S6671	177	
5268001	52680	BKBL108S5378	5621703	BDLL140S6656CF	188	

Injector Desp No.	Holder Desp No.	Holder Type Symbol No.	Nozzle Desp No.	Nozzle Type Symbol No.	Injector Working Pressure ( Bar )	Tab Code
5268002	52680	BKBL108S5378	5621704	BDLL160S6657CF	147	
5268003	52680	BKBL108S5378	5621705	BDLL160S6658CF	188	
5268004	52680	BKBL108S5378	5621733	BDLL157S6686	202	
5268301	52683	BKBL108S5451	5621840	BDLL150S6792CF	203	
5268302	52683	BKBL108S5451	5621843	BDLL150S6796CF	223	
5268303	52683	BKBL108S5451	5621858	BDLL150S6812CF	203	
5268304	52683	BKBL108S5451	5621858	BDLL150S6812CF	182	
5268305	52683	BKBL108S5451	5621896	BDLL150S6845CF	222	
5268400	52684	BKBL109S5022S	5620916	BDLL140S6205A	177	
5268401	52684	BKBL109S5022S	5620915	BDLL140S6205	177	
5268402	52684	BKBL109S5022S	5621000	BDLL140S6254	177	
5268601	52686	BKBL109S5063S	5621000	BDLL140S6254	178	
5268602	52686	BKBL109S5063S	5621052	BDLL140S6304	177	
5268801	52688	BKBL105S5476	5621904	BDLL140S6853CF	243	
5268802	52688	BKBL105S5476	5621936	BDLL140S6870CF	253	
5269101	52691	CKBL106S5337	5621611	BDLL150S6568	187	
5269801	52698	CKBL106S5357	5620695	BDLL150S6054	187	
5270001	52700	CKBL106S5364	5621611	BDLL150S6568	233	
5270002	52700	CKBL106S5364	5621695	BDLL155S6648	233	
5270301	52703	CKBL106S5382B	5621695	BDLL155S6648	233	
5271501	52715	BKBL112S561	5620890	BDLL140S6192	172	
5271601	52716	BKBL112S561M	5620770	BDLL140S6119	187	
5271602	52716	BKBL112S561M	5620890	BDLL140S6192	172	
5272401	52724	BKBL112S601	5620680	BDLL150S6028	177	
5272402	52724	BKBL112S601	5620695	BDLL150S6054	177	
5272403	52724	BKBL112S601	5620920	BDLL150S6208	177	
5272404	52724	BKBL112S601	5620950	BDLL150S6222	177	
5273001	52730	BKBL112S664	5620935	BDLL140S6214	172	
5273002	52730	BKBL112S664	5620975	BDLL140S6233	172	
5273003	52730	BKBL112S664	5621007	BDLL150S6261	172	
5273004	52730	BKBL112S664	5621045	BDLL150S6298	172	
5273006	52730	BKBL112S664	5621046	BDLL140S6298	172	
5273501	52735	BKBL112S5133	5621046	BDLL140S6298	172	
5273504	52735	BKBL112S5133	5620960	BDLL150S6225	177	
5274001	52740	BKBL112S5271B	5620960	BDLL150S6225	168	
5274003	52740	BKBL112S5271B	5621046	BDLL140S6298	162	
5274101	52741	BKBL112S5425	5620935	BDLL140S6214	173	
5274102	52741	BKBL112S5425	5620975	BDLL140S6233	173	
5274105	52741	BKBL112S5425	5621046	BDLL140S6298	173	
5274201	52742	BKBL112S5314B	5621290	BDLL150S6438	168	
5274202	52742	BKBL112S5314B	5621212	BDLL150S6397	198	
5274203	52742	BKBL112S5314B	5621213	BDLL150S6397A	162	
5274204	52742	BKBL112S5314B	5621673	BDLL150S6625	173	
5274205	52742	BKBL112S5314B	5621229	BDLL150S6407	162	
5274206	52742	BKBL112S5314B	5621765	BDLL150S6718CF	198	
5274301	52743	BKBL112S5460	5621765	BDLL150S6718CF	223	
5274401	52744	BKBL112S5339	5621666	BDLL150S6620	223	
5274402	52744	BKBL112S5339	5621694	BDLL140S6647	222	
5274601	52746	BKBL112S5347B	5621290	BDLL150S6438	192	
5274701	52747	BKBL112S5397	5621734	BDLL150S6687	198	
5274801	52748	BKBL112S5398	5621734	BDLL150S6687	202	
5274901	52749	CKBL113S5466	5621871	BDLL160S6830	202	
7274902	52749	CKBL113S5466	6801053	6801053	197	
5274903	52749	CKBL113S5466	6801078	6801078	197	
5277802	52778	BKBL130S5159	5629020	BDLL0S6409	42	

Injector Desp No.	Holder Desp No.	Holder Type Symbol No.	Nozzle Desp No.	Nozzle Type Symbol No.	Injector Working Pressure ( Bar )	Tab Code
5278301	52783	BKBL133S82	5620020	BDLL130S5	177	
5278801	52788	CKBL136S5468	5621866	BDLLA144S485	167	
5281601	52816	BKBL67S5299	5621550	BDLL150S6507	178	CF
5281602	52816	BKBL67S5299	5621125	BDLL150S6382	177	CG
5281603	52816	BKBL67S5299	5621513	BDLL150S6472	192	CD
5281604	52816	BKBL67S5299	5621518	BDLL150S6472BC	203	CE
5281605	52816	BKBL67S5299	5621550	BDLL150S6507	203	CL
5281606	52816	BKBL67S5299	5621513	BDLL150S6472	188	CM
5281607	52816	BKBL67S5299	5621085	BDLL150S6329CF	188	CN
5281608	52816	BKBL67S5299	5621285	BDLL150S6435	182	CP
5281609	52816	BKBL67S5299	5621588	BDLL150S6545	203	DL
5281610	52816	BKBL67S5299	5621181	BDLL150S6385A	203	DH
5281611	52816	BKBL67S5299	5621526	BDLL150S6486	192	DJ
5281612	52816	BKBL67S5299	5621517	BDLL150S6476	187	DK
5281613	52816	BKBL67S5299	5621597	BDLL150S6554	178	DN
5281614	52816	BKBL67S5299	5621619	BDLL150S6576	203	DU
5281615	52816	BKBL67S5299	5621619	BDLL150S6576	208	DV
5281616	52816	BKBL67S5299	5621125	BDLL150S6382	197	DW
5281617	52816	BKBL67S5299	5621074	BDLL150S6318	202	
5281618	52816	BKBL67S5299	5621636	BDLL150S6591	208	EA
5281619	52816	BKBL67S5299	5621647	BDLL150S6600	203	EG
5281620	52816	BKBL67S5299	5621649	BDLL150S6602CF	182	EE
5281621	52816	BKBL67S5299	5621208	BDLL150S6395	203	ET
5281622	52816	BKBL67S5299	5621707	BDLL150S6660	203	EZ
5281623	52816	BKBL67S5299	5621407	BDLL150S6457	203	EY
5281624	52816	BKBL67S5299	5621688	BDLL150S6642	203	FA
5281625	52816	BKBL67S5299	5621690	BDLL150S6643	203	FB
5281626	52816	BKBL67S5299	5621696	BDLL150S6649CF	203	FC
5281627	52816	BKBL67S5299	5621701	BDLL150S6654	203	FE
5281628	52816	BKBL67S5299	5621685	BDLL150S6639	203	FN
5281629	52816	BKBL67S5299	5621720	BDLL150S6673CF	208	FL
5281630	52816	BKBL67S5299	5621721	BDLL150S6674	178	FS
5281631	52816	BKBL67S5299	5621647	BDLL150S6600	178	FW
5281632	52816	BKBL67S5299	5621735	BDLL150S6688	203	FU
5281633	52816	BKBL67S5299	5621754	BDLL150S6708	215	FX
5281635	52816	BKBL67S5299	5621764	BDLL150S6713CF	208	GA
5281636	52816	BKBL67S5299	5621777	BDLL150S6730CF	208	HS
5281637	52816	BKBL67S5299	5621784	BDLL150S6737CF	203	GG
5281638	52816	BKBL67S5299	5621785	BDLL150S6738	203	GH
5281639	52816	BKBL67S5299	5621791	BDLL150S6743	178	GM
5281640	52816	BKBL67S5299	5621823	BDLL135S6776CF	208	GT
5281641	52816	BKBL67S5299	5621829	BDLL150S6786CF	203	GV
5281642	52816	BKBL67S5299	5621841	BDLL150S6793	203	
5281643	52816	BKBL67S5299	5621845	BDLL150S6798CF	208	HA
5281644	52816	BKBL67S5299	5621846	BDLL150S6799CF	208	HB
5281645	52816	CKBL67S5299	5621751	BDLL150S6705CF	202	
5281646	52816	CKBL67S5299	5621599	BDLL150S6556	212	
5281648	52816	BKBL67S5299	5621784	BDLL150S6737CF	218	HJ
5281649	52816	BKBL67S5299	5621875	BDLL135S6834CF	208	HK
5281650	52816	BKBL67S5299	5621890	BDLL150S6840CF	217	BFB
5281651	52816	BKBL67S5299	5621891	BDLL150S6841CF	187	BFA
5281653	52816	BKBL67S5299	5621784	BDLL150S6737CF	168	HY
5281654	52816	BKBL67S5299	5621764	BDLL150S6713CF	220	
5281701	52817	BKBL67SD5335	5621588	BDLL150S6545	197	
5281702	52817	BKBL67SD5335	5621513	BDLL150S6472	177	

Injector Desp No.	Holder Desp No.	Holder Type Symbol No.	Nozzle Desp No.	Nozzle Type Symbol No.	Injector Working Pressure ( Bar )	Tab Code
5281703	52817	BKBL67SD5335	5621649	BDLL150S6602CF	177	
5281704	52817	BKBL67SD5335	5621556	BDLL150S6513	172	
5281801	52818	BKBL67S5477	5621599	BDLL150S6556CF	173	
5282001	52820	BKBL67S5338	5621280	BDLL140S6433	168	
5282002	52820	BKBL67S5338	5621626	BDLL140S6581	168	
5282003	52820	BKBL67S5338	5621625	BDLL150S6582	168	
5282101	52821	BKBL67S5440	5621792	BDLL150S6745CF	203	GR
5282201	52822	BKBL67S5446	5621814	BDLL150S6771CF	244	GS
5282202	52822	BKBL67S5446	5621814	BDLL150S6771CF	203	HW
5285001	52850	BKBL67S5358	5621674	BDLL140S6626	157	
5285002	52850	BKBL67S5358	5621787	BDLL150S6740	157	
5285801	52858	BKBL67S5366	5621074	BDLL150S6318	243	EX
5285802	52858	BKBL67S5366	5621707	BDLL150S6660	227	FF
5285803	52858	BKBL67S5366	5621780	BDLL150S6734	254	3A
5285805	52858	BKBL67S5366	5621804	BDLL150S6760CF	203	3F
5285806	52858	BKBL67S5366	5621861	BDLL150S6815CF	203	3G
5285808	52858	BKBL67S5366	5621814	BDLL150S6771CF	248	HN
5287801	52878	BKBL69S5376	5621702	BDLL140S6655CF	213	
5287901	52879	BKBL69S5443	5621702	BDLL140S6655CF	213	
5287902	57879	BKBL69S5443	5621935	BDLL140S6869CF	213	
5288001	52880	BKBL97S5400	5621774	BDLL27S6697	177	
5288101	52881	CKBL97S5316	5620695	BDLL150S6054	187	
5288102	52881	CKBL97S5316	5620725	BDLL150S6078	175	
5288201	52882	BKBL97S5426	5621778	BDLL140S6732	233	
5288202	52882	BKBL97S5426	5621812	BDLL140S6768	233	
5288301	52883	BKBL99S5428	5621793	BDLL150S6746	197	
5288302	52883	BKBL99S5428	5621801	BDLL150S6757CF	197	
5288303	52883	BKBL99S5428	5621808	BDLL150S6761CF	197	
5288401	52884	BKBL97S5439	5621637	BDLL140S6592	178	
5288402	52884	BKBL97S5439	5621748	BDLL140S6592F	182	
5288601	52886	BKBL97S5454	5621802	BDLL160S6758CF	223	
5288602	52886	BKBL97S5454	5621853	BDLL150S6806CF	203	
5288603	52886	BKBL97S5454	5621854	BDLL155S6807CF	203	
5302001	53020	BKB32S630	5642010	RDN4S2	151	
5302061	53020	BKB32S630	5611640	BDL105S6125	121	G
5302062	53020	BKB32S630	5611650	BDL110S6133	121	D
5302063	53020	BKB32S630	5611635	BDL110S6116	162	
5302065	53020	BKB32S630	5611735	BDL110S6267	126	H
5302066	53020	BKB32S630	5611635	BDL110S6116	121	J
5302067	53020	BKB32S630	5611650	BDL110S6133	162	T
5302068	53020	BKB32S630	5611650	BDL110S6133	101	A
5302070	53020	BKB32S630	5611735	BDL110S6267	121	H
5302161	53021	BKB35SD630	5611635	BDL110S6116	121	
5302163	53021	BKB35SD630	5611730	BDL110S6257	141	
5303601	53036	BKB32S687	5642003	RDN8S1	146	
5303602	53036	BKB32S687	5643095	RDN4SD6299	162	
5304061	53040	BKB32SD5007	5611635	BDL110S6116	162	
5304661	53046	BKB22SD5026	5611635	BDL110S6116	121	J
5304662	53046	BKB32SD5026	5611640	BDL105S6125	121	
5304664	53046	BKB32SD5026	5611725	BDL95S6250	162	R
5304665	53046	BKB32SD5026	5611650	BDL110S6133	162	P2
5304666	53046	BKB32SD5026	5611730	BDL110S6257	141	M2
5304801	53048	BKB32S5058	5642003	RDN8S1	146	
5305061	53050	BKB32S5060	5611735	BDL110S6267	126	
5305062	53050	BKB32S5060	5611735	BDL110S6267	121	

Injector Desp No.	Holder Desp No.	Holder Type Symbol No.	Nozzle Desp No.	Nozzle Type Symbol No.	Injector Working Pressure ( Bar )	Tab Code
5305063	53050	BKB32S5060	5611650	BDL110S6133	101	
5305064	53050	BKB32S5060	5611650	BDL110S6133	121	
5305065	53050	BKB32S5060	5611650	BDL110S6133	162	
5305066	53050	BKB32S5060	5611650	BDL110S6133	132	
5305161	53051	BKB32SD5060	5611650	BDL110S6133	162	U
5305162	53051	BKB32SD5060	5611765	BDL95S6305	162	R
5305163	53051	BKB32SD5060	5611735	BDL110S6267	121	
5305164	53051	BKB32SD5060	5611650	BDL110S6133	121	
5305165	53051	BKB32SD5060	5612010	BDL100S6327	126	P
5305166	53051	BKB32SD5060	5611725	BDL95S6250	126	N
5305167	53051	BKB32SD5060	5611725	BDL95S6250	126	D
5305168	53051	BKB32SD5060	5612010	BDL100S6327	126	G
5306061	53060	BKB32S5085	5611635	BDL110S6116	121	
5306062	53060	BKB32S5085	5611640	BDL105S6125	121	
5306063	53060	BKB32S5085	5611650	BDL110S6133	121	DC
5306064	53060	BKB32S5085	5611650	BDL110S6133	162	
5306065	53060	BKB32S5085	5611735	BDL110S6267	126	
5306066	53060	BKB32S5085	5611650	BDL110S6133	136	DC
5306067	53060	BKB32S5085	5611735	BDL110S6267	121	AA
5306161	53061	BKB32SD5085	5611650	BDL110S6133	162	T
5306162	53061	BKB32SD5085	5611650	BDL110S6133	121	F
5306163	53061	BKB32SD5085	5611650	BDL110S6133	121	
5306164	53061	BKB32SD5085	5611730	BDL110S6257	141	M
5306165	53061	BKB32SD5085	5611735	BDL110S6267	121	X
5306301	53063	BKB32S5127	5611650	BDL110S6133	121	DA
5306302	53063	BKB32S5127	5611735	BDL110S6267	121	
5306303	53063	BKB32S5127	5611735	BDL110S6267	121	DB
5306401	53064	BKB32SD5127	5611650	BDL110S6133	121	P
5306402	53064	BKB32SD5127	5611730	BDL110S6257	141	M
5306403	53064	BKB32SD5127	5611735	BDL110S6267	121	K
5306601	53066	BKB32SD5127E	5611650	BDL110S6133	121	
5306801	53068	BKB32S5140	5643095	RDN4SD6299	162	
5306802	53068	BKB32S5140	5642003	RDN8S1	146	
5306901	53069	BKB32SD5140	5641015	BDN0SD21	136	
5307001	53070	BKB32S5141	5611735	BDL110S6267	121	H
5307002	53070	BKB32S5141	5611650	BDL110S6133	121	F
5307003	53070	BKB32S5141	5611650	BDL110S6133	162	BT
5307004	53070	BKB32S5141	5611650	BDL110S6133	101	A
5307201	53072	BKB32SD5141	5611650	BDL110S6133	121	
5307202	53072	BKB32SD5141	5611735	BDL110S6267	121	
5307203	53072	BKB32SD5141	5611725	BDL95S6250	126	
5307204	53072	BKB32SD5141	5612010	BDL100S6327	126	G
5307205	53072	BKB32SD5141	5611735	BDL110S6267	121	E
5307206	53072	BKB32SD5141	5611765	BDL95S6305	162	R
5307207	53072	BKB32SD5141	5611650	BDL110S6133	162	U
5307208	53072	BKB32SD5141	5612143	BDL95S6520	146	
5308501	53085	BKB32SD5253	5611650	BDL110S6133	121	
5308502	53085	BKB32SD5253	5611735	BDL110S6267	121	
5309502	53095	BKB32SD5254	5611650	BDL110S6133	121	
5309503	53095	BKB32SD5254	5611735	BDL110S6267	172	
5309601	53096	BKB32SD5343	5611650	BDL110S6133	136	
5309602	53096	BKB32SD5343	5611725	BDL95S6250	141	
5309801	53098	BKB32S5255	5611735	BDL110S6267	121	
5309901	53099	BKB32S5343	5611735	BDL110S6267	126	
5310501	53105	BKB35S24	5642001	BDN4S1	126	

Injector Desp No.	Holder Desp No.	Holder Type Symbol No.	Nozzle Desp No.	Nozzle Type Symbol No.	Injector Working Pressure ( Bar )	Tab Code
5310502	53105	BKB35S24	5642010	RDN4S2	151	
5310503	53105	BKB35S24	5642015	BDN30S2	177	
5310504	53105	BKB35S24	5642013	RDN8S2	121	
5310505	53105	BKB35S24	5642014	BDN15S2	121	
5310561	53105	BKB35S24	5610035	BDL0S421	151	
5310562	53105	BKB35S24	5611545	BDL140S6071	141	
5310563	53105	BKB35S24	5610030	BDL0S336	141	
5310564	53105	BKB35S24	5611605	BDL90S6106	172	
5311001	53110	BKB35SD51	5643014	BDN12SD12	106	
5311003	53110	BKB35SD51	5641015	BDN0SD21	111	
5314701	53147	BKB35SD501	5643014	BDN12SD12	106	
5314801	53148	BKB35SP501	5651010	BDN12SP2	101	
5314901	53149	BKB35SD502	5643014	BDN12SD12	106	
5315001	53150	BKB35SP502	5651010	BDN12SP2	101	
5316302	53163	BKB35S535	5642003	RDN8S1	111	
5319801	53198	BKB35SD582	5643014	BDN12SD12	116	
5321001	53210	BKB35S6135	5643036	BDN4SD508W	136	
5321002	53210	BKB35S6135	5643060	BDN4SD6164W	136	
5324001	53303	BKB35S668	5651052	RDN12SPC6A	116	
5324002	53303	BKB35S668	5651110	BDN12SP6169	116	
5324101	53241	BKB35S668M	5651050	BDN12SP6A	116	
5324301	53243	BKB35S671	5642014	BDN15S2	121	
5324302	53243	BKB35S671	5642001	BDN4S1	151	
5324303	53243	BKB35S671	5642013	RDN8S2	101	
5324304	53243	BKB35S671	5642010	RDN4S2	151	
5324401	53244	BKB35SD671	5643014	BDN12SD12	126	
5325001	53250	BKB35S680S	5651052	RDN12SPC6A	126	
5325002	53250	BKB35S680S	5651090	BDN4SP6165W	126	
5327161	53271	BKB35S5018M	5611710	BDL15S6230	177	
5327162	53271	BKB35S5018M	5611720	BDL15S6247	177	
5327163	53271	BKB35S5018M	5611710	BDL15S6230	202	
5327165	53271	BKB35S5018M	5611720	BDL15S6247	202	
5327701	53277	BKB35S5055S	5642009	RDN8S2W	146	
5327901	53279	BKB35S5058H	5642013	RDN8S2	146	
5328061	53280	BKB35S5073	5611710	BDL15S6230	243	
5328062	53280	BKB35S5073	5611720	BDL15S6247	243	
5328063	53280	BKB35S5073	5612140	BDL15S6497	243	
5328064	53280	BKB35S5073	5612150	BDL60S6541	244	
5328261	53282	BKB35S5074	5611710	BDL15S6230	168	
5328262	53282	BKB35S5074	5611710	BDL15S6230	243	
5328263	53282	BKB35S5074	5611720	BDL15S6247	243	
5328601	53286	BKB35S5091	5650071	BDN0SPC6189	121	
5328701	53287	BKB35SD5091	5650091	RDN0SPC6209	141	
5328702	53287	BKB35SD5091	5650300	RDN0SPC6389	141	
5329001	53290	BKB35S5103	5643041	BDN8SD510A	116	
5329501	53295	BKB35S5118	5642120	BDN4S6308	131	
5329505	53295	BKB35S5118	5643085	RDN12SD6236	140	
5329506	53295	BKB35S5118	5643430	RDN12SD6498	121	
5329507	53295	BKB35S5118	5643380	BDN0SD6479	140	
5329508	53295	BKB35S5118	5643450	BDN12SD6517	131	
5329509	53295	BKB35S5118	R5643410	RDN0SDC6577	120	
5329509B	53295	BKB35S5118	5643413	RDN0SDC6577B	111	
5330101	53301	BKB35S5136	5651241	RDN12SPC6290	121	
5330301	53303	BKB35S5153	5651050	BDN12SP6A	107	
5330302	53303	BKB35S5153	5621241	RDN12SPC6290	116	

Injector Desp No.	Holder Desp No.	Holder Type Symbol No.	Nozzle Desp No.	Nozzle Type Symbol No.	Injector Working Pressure ( Bar )	Tab Code
5330303	53303	BKB35S5153	5642010	RDN4S2	101	
5330401	53304	BKB35S5153M	5651050	BDN12SP6A	116	
5330501	53305	BKB35S5156	5651380	RDN12SDC6399	125	
5330901	53309	BKB35S5164	5641300	BDN12SDC6335	108	
5332101	53321	BKB35S5184	5651380	RDN12SDC6399	121	
5332301	53323	BKB35S5185	5642090	RDN4S6157	141	
5332501	53325	BKB35S5186M	5611710	BDL15S6230	243	
5332502	53325	BKB35S5186M	5611720	BDL15S6247	243	
5332701	53327	BKB35S5187M	5611710	BDL15S6230	177	
5332901	53329	BKB35S5188	5650071	BDN0SPC6189	121	
5333101	53331	BKB35SD5188	5650091	RDN0SPC6209	142	
5333102	53331	BKB35SD5188	5650300	RDN0SPC6389	137	
5333103	53331	BKB35SD5188	5650091	RDN0SPC6209	131	
5333104	53331	BKB35SD5188	5650350	RDN0SPC6651	137	
5333105	53331	BKB35SD5188	5650300	RDN0SPC6389	127	
5333301	53333	BKB35S5189	5651241	RDN12SPC6290	122	
5333302	53333	BKB35S5189	5651241	RDN12SPC6290	142	
5333303	53333	BKB35S5189	5650091	RDN0SPC6209	131	
5333501	53335	BKB35S5190	5651320	RDN4SC6391	126	
5335001	53350	BKB35S5199	5641030	RDN0SD514	126	
5336001	53360	BKB35S5200	5643085	RDN12SD6236	131	
5336002	53360	BKB35S5200	5643085	RDN12SD6236	126	
5336101	53361	BKB35SD5200	5643085	RDN12SD6236	136	
5339002	53390	BKB35S5206	5643085	RDN12SD6236	126	
5340001	53400	BKB35SD5207	5643230	RDN4SDC6444	147	
5340101	53401	BKB35S5207	5643085	RDN12SD6236	151	
5342002	53420	BKB35S5210	5642090	RDN4S6157	167	
5342701	53427	BKB35S5217	5643330	RDN12SD6459	131	
5343001	53430	BKB35SD5220	5611635	BDL110S6116	121	
5343101	53431	BKB35S5220	5611620	BDL80S6109	146	
5343301	53433	CKB35S5243	5611735	BDL110S6267	132	
5343501	53435	CKB35SD5244	5641080	RDN0SDC6434	132	
5343601	53436	BKB35SD5427	5641015	BDN0SD21	123	
5343701	53437	BKB35SD5431	5641891	RDN0SDC6751	115	
5344001	53440	BKB35S5237	5650300	RDN0SPC6389	127	
5344501	53445	BKB35S5246	5641015	BDN0SD21	120	
5344601	53446	BKB35SD5247	5643085	RDN12SD6236	142	BW
5344602	53446	BKB35SD5247	5643105	RDN4SD6346	142	CJ
5344603	53446	BKB35SD5247	5641015	BDN0SD21	123	
5344604	53446	BKB35SD5247	5643069	RDN4SD6769	142	GZ
5344701	53447	BKB37S5327	5641015	BDN0SD21	142	
5344702	53447	BKB37S5327	5641860	BDN0SD6595	135	
5344703	53447	BKB37S5327	5641870	RDN0SD6596	132	
5344801	53448	BKB40S697X	5651241	RDN12SPC6290	136	
5344802	53448	BKB40S697X	5651261	BDN4SPC6312	136	
5344803	53448	BKB40S697X	5651450	BDN4SPC6460	136	
5344901	53449	BKB40S5003TF	5642090	RDN4S6157	131	
5344902	53449	BKB40S5003TF	5642090	RDN4S6157	126	
5344903	53449	BKB40S5003TF	5642090	RDN4S6157	162	I
5344904	53449	BKB40S5003V	5642090	RDN4S6157	131	
5344905	53449	BKB40S5003V	5642090	RDN4S6157	126	
5344906	53449	BKB40S5003V	5642090	RDN4S6157	162	I
5345001	53450	BKB40S697	5642090	RDN4S6157	126	
5345002	53450	BKB40S697	5641120	BDN12SP6184	151	
5345003	53450	BKB40S697	5651130	BDN4SP6188	136	

Injector Desp No.	Holder Desp No.	Holder Type Symbol No.	Nozzle Desp No.	Nozzle Type Symbol No.	Injector Working Pressure ( Bar )	Tab Code
5345004	53450	BKB40S697	5651052	RDN12SPC6A	136	
5345005	53450	BKB40S697	5651110	BDN12SP6169	136	
5345006	53450	BKB40S697	5650091	RDN0SPC6209	136	
5345007	53450	BKB40S697	5650070	BDN0SP6189	136	
5345101	53451	BKB40S697K	5651111	BDN12SP6169A	136	
5345102	53451	BKB40S697K	5651170	BDN12SP6262	136	
5345103	53451	BKB40S697K	5651131	BDN4SP6188A	136	
5345104	53451	BKB40S697K	5651190	BDN4SP6263	136	
5345105	53451	BKB40S697K	5651240	BDN12SP6290	136	
5345106	53451	BKB40S697K	5651260	BDN4SP6312	136	
5345107	53451	BKB40S697K	5651190	BDN4SP6263	136	
5345108	53451	BKB40S697K	5651241	RDN12SPC6290	136	
5345109	53451	BKB40S697K	5651450	BDN4SPC6460	136	
5345110	53451	BKB40S697K	5651052	RDN12SPC6A	136	
5345201	53452	BKB40S5003F	5642090	RDN4S6157	121	G
5345202	53452	BKB40S5003F	5642090	RDN4S6157	131	L
5345203	53452	BKB40S5003F	5642090	RDN4S6157	162	T
5345204	53452	BKB40S5003F	5643085	RDN12SD6236	121	F
5345205	53452	BKB40S5003F	5642090	RDN4S6157	126	D
5345301	53453	BKB40S5003	5642090	RDN4S6157	162	T
5345401	53454	BKB40S5003N	5643085	RDN12SD6236	121	F
5345402	53454	BKB40S5003N	5642090	RDN4S6157	162	T
5345403	53454	BKB40S5003N	5642090	RDN4S6157	121	G
5345404	53454	BKB40S5003N	5642090	RDN4S6157	131	L
5345501	53455	BKB40S5008R	5650091	RDN0SPC6209	136	
5345601	53456	BKB40S5008	5651052	RDN12SPC6A	151	
5345602	53456	BKB40S5008	5643085	RDN12SD6236	136	
5345701	53457	BKB40SD5008D	5650090	BDN0SP6209	136	
5345702	53457	BKB40SD5008D	5642090	RDN4S6157	141	
5345801	53458	BKB40S5008N	5643085	RDN12SD6236	121	
5345802	53458	BKB40S5008N	5642090	RDN4S6157	162	
5345901	53459	BKB40SD5008R	5650090	BDN0SP6209	121	
5345902	53459	BKB40SD5008R	5650091	RDN0SPC6209	136	
5346001	53460	BKB40S5092F	5643085	RDN12SD6236	121	
5346101	53461	BKB40S5092TF	5643085	RDN12SD6236	121	H
5346102	53461	BKB40S5092V	5643085	RDN12SD6236	121	H
5346901	53469	BKB40S5105	5643085	RDN12SD6236	121	
5346902	53469	BKB40S5105	5643085	RDN12SD6236	136	
5346903	53469	BKB40S5105	5642090	RDN4S6157	136	
5346904	53469	BKB40S5105	5643085	RDN12SD6236	141	
5346905	53469	BKB40S5105	5643085	RDN12SD6236	131	
5347001	53470	BKB40S5105T	5643085	RDN12SD6236	136	S
5347101	53471	BKB40S5105TF	5643085	RDN12SD6236	126	
5347102	53471	BKB40S5105V	5643085	RDN12SD6236	126	
5347103	53471	BKB40S5105V	5643085	RDN12SD6236	136	
5347201	53472	BKB40SD5105TF	5643085	RDN12SD6236	126	
5347301	53473	BKB40S5144V	5642090	RDN4S6157	131	L
5347302	53473	BKB40S5144V	5642090	RDN4S6157	126	D
5347303	53473	BKB40S5144V	5642090	RDN4S6157	162	T
5347304	53473	BKB40S5144V	5642090	RDN4S6157	121	G
5347305	53473	BKB40S5144V	5643085	RDN12SD6236	121	F
5347601	53476	BKB40S5145V	5643330	RDN12SD6459	131	AH
5347701	53477	BKB40S5146V	5643085	RDN12SD6236	121	H
5347801	53478	BKB40S5146VH	5643085	RDN12SD6236	121	HP
5347901	53479	BKB40S5147V	5643085	RDN12SD6236	126	E

Injector Desp No.	Holder Desp No.	Holder Type Symbol No.	Nozzle Desp No.	Nozzle Type Symbol No.	Injector Working Pressure ( Bar )	Tab Code
5347902	53479	BKB40S5147V	5643085	RDN12SD6236	131	M
5347903	53479	BKB40S5147V	5642090	RDN4S6157	131	AE
5348001	53480	BKB40S5162	5650091	RDN0SPC6209	136	
5348201	53482	BKB40SD5147V	5643085	RDN12SD6236	126	J
5348202	53482	BKB40SD5147V	5643085	RDN12SD6236	146	AM
5348203	53482	BKB40SD5147V	5643085	RDN12SD6236	136	AT
5348301	53483	BKB40S5225	5651241	RDN12SPC6290	141	
5348302	53483	BKB40S5225	5651450	BDN4SPC6460	141	
5349001	53490	BKB40S5221	5642090	RDN4S6157	131	L
5349002	53490	BKB40S5221	5642090	RDN4S6157	157	BJ
5349003	53490	BKB40S5221	5642090	RDN4S6157	126	D
5349004	53490	BKB40S5221	5643085	RDN12SD6236	121	F
5349101	53491	BKB40S5221N	5642090	RDN4S6157	131	
5349102	53491	BKB40S5221N	5643085	RDN12SD6236	121	F
5350001	53500	BKB40S5222	5643330	RDN12SD6459	127	BH
5350802	53508	BKBL97S5064	5620815	BDLL90S6147	177	
5351001	53510	BKB40S5223	5643085	RDN12SD6236	117	BK
5352001	53520	BKB40S5224	5642090	RDN4S6157	127	BE
5352002	53520	BKB40S5224	5643085	RDN12SD6236	122	M
5352003	53520	BKB40S5224	5643085	RDN12SD6236	126	BL
5352101	53521	BKB40SD5224	5643085	RDN12SD6236	147	BF
5352102	53521	BKB40SD5224	5643085	RDN12SD6236	142	BG
5352103	53521	BKB40SD5224	5643085	RDN12SD6236	127	J
5352104	53521	BKB40SD5224	5643069	RDN4SD6769	142	GY
5353001	53530	BKB40S5272	5651241	RDN12SPC6290	132	
5353002	53530	BKB40S5272	5651450	BDN4SPC6460	132	
5353101	53531	BKB40S5276	5650091	RDN0SPC6209	127	
5353201	53532	BKB40SD5276	5650091	RDN0SPC6209	132	
5353301	53533	BKB40S5276N	5643085	RDN12SD6236	121	
5353302	53533	BKB40S5276N	5642090	RDN4S6157	162	
5353501	53535	BKB40S5277	5650091	RDN0SPC6209	136	
5353603	53536	CKB40S5317	5643085	RDN12SD6236	131	
5353801	53536	CKB40SD5317	5643085	RDN12SD6236	151	
5354601	53546	BKB41S5160	5641420	RDN0SDC6419	125	
5355501	53555	BKB40SD5412	5643085	RDN12SD6236	136	
5356302	53563	BKB45SD5373	R5643410	RDN0SDC6577	115	
5356501	53565	BKB45SD5422	R5643410	RDN0SDC6577	116	
5356501B	53565	BKB45SD5422	5643413	RDN0SDC6577B	116	
5356502	53565	BKB45SD5422	5641891	RDN0SDC6751	127	
5356503C	53565	BKB45SD5422	5641904	RDN0SDC6850C	125	
5356601	53566	BKB45SD5422M	R5643410	RDN0SDC6577	111	
5356701	53567	BKB45S5456	5641891	RDN0SDC6751	115	
5356701C	53567	BKB45S5456	5641906	RDN0SDC6751C	116	
5356701G	53567	BKB45S5456	5641923	RDN0SDC6751G	116	
5356702	53567	BKB45S5456	5643073	RDN12SDC6849	116	
5356801	53568	BKB45S5456M	5641891	RDN0SDC6751	112	
5360601	53606	BKB50S19B	5643014	BDN12SD12	116	
5360701	53607	BKB50SD19B	5643014	BDN12SD12	162	
5360804	53608	BKB50S24	5642013	RDN8S2	111	
5363961	53639	BKB50S73	5611255	BDL160S519	91	
5364661	53646	BKB50S87	5611665	BDL106S6142	121	
5364662	53646	BKB50S87	5611665	BDL106S6142	101	A
5364663	53646	BKB50S87	5611620	BDL80S6109	101	
5366101	53661	BKB50S501	5642027	BDN15S3	101	
5366102	53661	BKB50S501	5642013	RDN8S2	177	

Injector Desp No.	Holder Desp No.	Holder Type Symbol No.	Nozzle Desp No.	Nozzle Type Symbol No.	Injector Working Pressure ( Bar )	Tab Code
5366103	53661	BKB50S501	5642010	RDN4S2	177	
5367061	53670	BKB50S531	5611250	BDL160S518	177	
5367200	53672	BKB50S533B	5642009	RDN8S2W	177	
5367201	53672	BKB50S533B	5642015	BDN30S2	116	
5367300	53673	BKB50SD533B	5643014	BDN12SD12	162	
5367302	53673	BKB50SD533B	5643014	BDN12SD12	177	
5369201	53692	BKB60S565	5642001	BDN4S1	177	
5369202	53692	BKB60S565	5642001	BDN4S1	121	
5371301	53713	BKB50S612S	5642011	BDN4S2W	151	
5371302	53713	BKB50S612S	5641016	BDN0SD21W	151	
5371303	53713	BKB50S612S	5641016	BDN0SD21W	162	
5371501	53715	BKB50S613S	5643060	BDN4SD6164W	126	
5371502	53715	BKB50S613S	5642013	RDN8S2	136	
5372201	53722	BKB50S622	5642001	BDN4S1	177	
5373801	53738	BKB50S655	5642009	RDN8S2W	121	
5373901	53739	BKB50S655S	5642008	BDN6S2W	121	
5373902	53739	BKB50S655S	5642009	RDN8S2W	116	
5375201	53752	BKB50S671	5642001	BDN4S1	116	
5375202	53752	BKB50S671	5642002	BDN6S1	116	
5375301	53753	BKB50SD671	5643014	BDN12SD12	116	
5375801	53758	BKB50S675	5641015	BDN0SD21	106	
5375802	53758	BKB50S675	5642001	BDN4S1	121	
5376301	53763	BKB50S679	5642001	BDN4S1	121	
5385001	53850	BKB50S5188	5650091	RDN0SPC6209	132	
5385002	53850	CKB50S5188	5650091	RDN0SPC6209	175	
5385004	53850	BKB50S5188	5643470	BDN12SD6861	141	
5385101	53851	BKB50S5496	5650091	RDN0SPC6209	132	
5385401	53854	CKB50SD5445	5641080	RDN0SDC6434	151	
5388501	53885	BKB51SD5236	5641800	RDN0SD6475	126	
5388601	53886	CKB50S5447	5641080	RDN0SDC6434	136	
5388801	53888	CKB50SD5457	5641080	RDN0SDC6434	151	
5389001	53890	BKB51SD5274	5641800	RDN0SD6475	126	
5391501	53901	BKB58S5047	5641015	BDN0SD21	131	
5391701	53917	BKB58S5052	5641015	BDN0SD21	131	
5392061	53920	BKB58S5072	5611740	BDL50S6270	151	
5392062	53920	BKB58S5072	5641015	BDN0SD21	131	
5392801	53928	BKB60S613S	5643060	BDN4SD6164W	131	
5393201	53932	BKB60S655S	5643015	BDN12SD12WT	146	
5393202	53932	BKB60S655S	5641015	BDN0SD21	136	
5398001	53980	BKB65S655S	5643066	BDN4SD6207W	136	
5398002	53980	BKB65S655S	5651380	RDN12SDC6399	157	
5398103	53981	BKB65S5331	5651380	RDN12SDC6399	148	
5398501	53985	BKB66S5393	5643014	BDN12SD12	142	
5411801	54118	BKB70S640	5643015	BDN12SD12WT	136	
5412201	54122	BKB70S5016	5643015	BDN12SD12WT	136	
5413061	54130	BKB70SY5112	5612020	BDL58SY6353	136	
5418501	54185	BKB78SD5071	5651070	BDN12SP8A	116	
5418601	54186	BKB78SD5081	5651070	BDN12SP8A	116	
5421101	54211	BKB80S24	5642003	RDN8S1	121	
5421102	54211	BKB80S24	5642013	RDN8S2	111	
5421103	54211	BKB80S24	5642015	BDN30S2	126	
5421108	54211	BKB80S24	5642001	BDN4S1	136	
5421163	54211	BKB80S24	5640035	BDL0S421	136	
5421164	54211	BKB80S24	5612015	BDL48SY6343	136	
5421501	54215	BKB80SD51	5643014	BDN12SD12	106	

<b>Injector Desp No.</b>	<b>Holder Desp No.</b>	<b>Holder Type Symbol No.</b>	<b>Nozzle Desp No.</b>	<b>Nozzle Type Symbol No.</b>	<b>Injector Working Pressure ( Bar )</b>	<b>Tab Code</b>
5422661	54226	BKB80S56	5611255	BDL160S519	121	
5423661	54236	BKB80S66B	5611675	BDL40S6155	157	
5423662	54236	BKB80S66B	5611680	BDL56S6160	157	
5423663	54236	BKB80S66B	5611685	BDL55S6161	157	
5423664	54236	BKB80S66B	5611690	BDL50S6162	157	
5424461	54244	BKB80S73	5611255	BDL160S519	177	
5426161	54261	BKB80S93B	5611265	BDL140S521	168	
5426162	54261	BKB80S93B	5611580	BDL140S6089	168	
5428461	54284	BKB80S531	5611255	BDL160S519	177	
5429201	54292	BKB80S536	5611435	BDL21S661	177	
5434801	54348	BKB80S619	5651070	BDN12SP8A	126	
5436401	54364	BKB80S640	5643014	BDN12SD12	136	
5436402	54364	BKB80S640	5643015	BDN12SD12WT	122	
5436403	54364	BKB80S640	5643065	BDN4SD24	131	
5436761	54367	BKB80S650	5611600	BDL150S6105	151	
5436901	54369	BKB80S651	5642013	RDN8S2	117	
5438801	54388	BKB80S671	5611410	BDL48S648	151	
5438802	54388	BKB80S671	5642015	BDN30S2	126	
5438803	54388	BKB80S671	5642003	RDN8S1	121	
5438804	54388	BKB80S671	5642001	BDN4S1	136	
5438805	54388	BKB80S671	5610035	BDL0S421	136	
5438806	54388	BKB80S671	5612015	BDL48SY6343	136	
5438807	54388	BKB80S671	5610065	BDL0S545	141	
5438808	54388	BKB80S671	5651070	BDN12SP8A	116	
5438901	54389	BKB80SD671	5643014	BDN12SD12	106	
5439501	54395	BKB80S690	5643036	BDN4SD508W	131	
5440701	54407	BKB80S5016	5641050	RDN0SD6206	141	
5446002	54460	BKB80S5153	5611600	BDL150S6105	151	
5446003	54460	BKB80S5153	5651500	RDN4SP6547	106	
5446004	54460	BKB80S5153	5651500	RDN4SP6547	106	
5449502	54495	BKB82SD5248B	5643320	BDN4SDC6453	151	
5449801	54498	BKB80SD5262B	5643014	BDN12SD12	162	
5451001	54510	BKB82SD5263B	5643320	BDN4SDC6453	151	
5452001	54520	BKB83S5286	5642001	BDN4S1	136	
5452002	54520	BKB83S5286	5610035	BDL0S421	136	
5452003	54520	BKB83S5286	5611410	BDL48S648	151	
5452004	54520	BKB83S5286	5642013	RDN8S2	111	
5453601	54536	BKB89SD5036	5643014	BDN12SD12	151	
5457601	54576	BKB91S5288	5642013	RDN8S2	147	
5458601	54586	BKB91S5307	5651500	RDN4SP6547	147	
5462601	54626	BKB95S613S	5643066	BDN4SD6207W	136	
5463501	54635	BKB95S640	5643014	BDN12SD12	131	
5463502	54635	BKB95S640	5643036	BDN4SD508W	131	
5463503	54635	BKB95S640	5643015	BDN12SD12WT	136	
5464001	54640	BKB95S5016	5643015	BDN12SD12WT	136	
5464961	54649	BKB95S5020	5611480	BDL28.5S6009	168	
5465261	54652	BKB95S5110	5611480	BDL28.5S6009	233	
5468701	54687	BKB97S5301	5612141	BDL100S6503	162	
5472501	54725	BKB105S5045	5643025	BDN4SD505	138	
5474361	54743	BKB115S539	5611415	BDL116S649	141	
5474701	54747	BKB115S547	5611390	BDL160S636	126	
5476461	54764	BKB115S5059B	5611670	BDL134S6145	202	
5490001	54900	BKB35S5257	5643095	RDN4SD6299	152	
5490002	54900	BKB35S5257	5643095	RDN4SD6299	137	
5490003	54900	BKB35S5257	5642003	RDN8S1	137	

Injector Desp No.	Holder Desp No.	Holder Type Symbol No.	Nozzle Desp No.	Nozzle Type Symbol No.	Injector Working Pressure ( Bar )	Tab Code
5490004	54900	BKB35S5257	5642001	BDN4S1	102	
5490301	54903	BKB35S5258	5611735	BDL110S6267	117	DE
5490302	54903	BKB35S5258	5611650	BDL110S6133	117	DD
5490401	54904	BKB35SD5258	5612162	BDL110S6709	178	GW
5490501	54905	BKB35S5259	5611650	BDL110S6133	117	BN
5490502	54905	BKB35S5259	5611650	BDL110S6133	92	AY
5490503	54905	BKB35S5259	5611650	BDL110S6133	137	AX
5490504	54905	BKB35S5259	5611735	BDL110S6267	121	AZ
5490506	54905	BKB35S5259	5611640	BDL105S6125	121	BG
5490507	54905	BKB35S5259	5611635	BDL110S6116	121	J
5490601	54904	BKB35SD5259	5611650	BDL110S6133	127	BA
5490602	54904	BKB35SD5259	5611650	BDL110S6133	162	T
5490603	54904	BKB35SD5259	5611730	BDL110S6257	141	M
5490604	54904	BKB35SD5259	5611650	BDL110S6133	162	P
5490605	54904	BKB35SD5259	5611725	BDL95S6250	162	R
5490606	54904	BKB35SD5259	5611735	BDL110S6267	122	K
5490607	54904	BKB35SD5259	5611635	BDL110S6116	122	J
5490608	54904	BKB35SD5259	5611735	BDL110S6267	188	EM
5490609	54904	BKB35SD5259	5611735	BDL110S6267	178	FJ
5490610	54904	BKB35SD5259	5611650	BDL110S6133	185	FT
5490611	54904	BKB35SD5259	5612162	BDL110S6709	178	GC
5490701	54907	BKB35S5260	5611735	BDL110S6267	117	BM
5490702	54907	BKB35S5260	5611650	BDL110S6133	112	BB
5490703	54907	BKB35S5260	5611650	BDL110S6133	92	A
5490704	54907	BKB35S5260	5612160	BDL110S6610	162	
5490705	54907	BKB35S5260	5611650	BDL110S6133	162	
5490801	54908	BKB35SD5260	5611650	BDL110S6133	127	BC
5490802	54908	BKB35SD5260	5611725	BDL95S6250	127	BD
5490803	54908	BKB35SD5260	5611735	BDL110S6267	122	BM
5490804	54908	BKB35SD5260	5611650	BDL110S6133	162	U
5490805	54908	BKB35SD5260	5611735	BDL110S6267	188	EV
5490806	54908	BKB35SD5260	5612151	BDL110S6685	178	FM
5490807	54908	BKB35SD5260	5611735	BDL110S6267	178	FR
5490808	54908	BKB35SD5260	5612162	BDL110S6709	178	GB
5490901	54909	BKB35SD5261	5621938	BDL110S6879	190	
5493001	54930	BKB35S5283	5650091	RDN0SPC6209	137	
5493301	54933	BKB35S5286	5642013	RDN8S2	101	
5493302	54933	BKB35S5286	5642010	RDN4S2	142	
5493303	54933	BKB35S5286	5642014	BDN15S2	121	
5493401	54934	BKB35SD5286	5643014	BDN12SD12	126	
5493901	54939	BKB35S5300	5642091	BDN4S6157L	151	
5494201	54942	BKB35S5303	5650300	RDN0SPC6389	136	
5494202	54942	BKB35S5303	5650300	RDN0SPC6390	177	
5495401	54954	CKB35S5315	5611735	BDL110S6267	131	
5495801	54958	CKB35SD5319	5641080	RDN0SDC6434	131	
5496002	54960	BKB35SD5321	5642091	BDN4S6157L	131	BZ
5496101	54961	BKB35SD5321	5643085	RDN12SD6236	136	CB
5497001	54970	BKB35S5355	5611650	BDL110S6133	162	
5497002	54970	BKB35S5355	5612160	BDL110S6610	162	EU
5497006	54970	BKB35S5355	5612160	BDL110S6610	162	EV
5497601	54976	BKB35SD5379	R5643410	RDN0SDC6577	115	
5497602	54976	BKB35SD5379M	R5643410	RDN0SDC6577	115	
5498001	54980	BKB35SD5410	5643105	RDN4SD6346	142	FZ
5498002	54980	BKB35SD5410	5641080	RDN0SDC6434	142	GP
5570301	55703	YNH11	5643014	BDN12SD12	107	

**INJECTOR LIST - Nov 07 - 26 of 36**

<b>Injector Desp No.</b>	<b>Holder Desp No.</b>	<b>Holder Type Symbol No.</b>	<b>Nozzle Desp No.</b>	<b>Nozzle Type Symbol No.</b>	<b>Injector Working Pressure ( Bar )</b>	<b>Tab Code</b>
5570601	55706	YNH9	5642120	BDN4S6308	102	
5570801	55708	YNH8	5643014	BDN12SD12	97	
5656401	56564	BKB45SD5413	R5643410	RDN0SDC6577	112	
5740001	57400	NSD0B031D0484	5620960	BDLL150S6225	158	
6700101	67001	LRB67001	6801001	6801001	256	
6700102	67001	LRB67001	6801003	6801003	256	
6700501	67005	LRB67005	5643412	RDN0SD6577A	116	
6700502	67005	LRB67005	5641032	RDN0SD6827	128	
6700503	67005	LRC67005	5641895	BDN0SD1930	126	
6700701	67007	LRB67007	6801006	6801006	246	
6700801	67008	LRB67008	6809224	6809224	189	
6700802	67008	LRB67008	6809225	6809225	200	
6700803	67008	LRB67008	6809325	6809325	197	
6700804	67008	LRB67008	6801015	6801015	200	
6700805	67008	LRB67008	6801016	6801016	200	
6700806	67008	LRB67008	6801017	6801017	200	
6700807	67008	LRB67008	6801018	6801018	200	
6700808	67008	LRB67008	6809295	6809295	200	
6700809	67008	LRB67008	6801035	6801035	200	
6700810	67008	LRB67008	6801101	6801101	203	
6701042	67010	LRB67010	6801019	6801019	200	
6701201	67012	LRB67012	5643070	RDN4SDC6794	139	
6701301	67013	LRB67013	6801009	6801009	235	
6701302	67013	LRB67013	6801010	6801010	235	
6701303	67013	LRB67013	6801011	6801011	235	
6701401	67014	LRB67014	6801014	6801014	240	HC
6701402	67014	LRB67014	6801019	6801019	225	HE
6701403	67014	LRB67014	6801022	6801022	205	HF
6701404	67014	LRB67014	6801022	6801022	225	HG
6701406	67014	LRB67014	6801019	6801019	245	HH
6701407	67014	LRB67014	6801027	6801027	225	HL
6701408	67014	LRB67014	6801014	6801014	220	HP
6701409	67014	LRB67014	6801045	6801045	266	HR
6701410	67014	LRV67014	6801022	6801022	253	BFIE
6701411	67014	LRV67014	6801047	6801047	205	BFD
6701412	67014	LRB67014	6801019	6801019	195	HT
6701413	67014	LRB67014	6801022	6801022	215	HU
6701414	67014	LRB67014	6801052	6801052	245	HV
6701415	67014	LRB67014	6801029	6801029	215	HZ
6701416	67014	LRB67014	6801057	6801057	245	JA
6701417	67014	LRB67014	6801058	6801058	245	JB
6701418	67014	LRB67014	6801058	6801058	215	JE
6701419	67014	LRB67014	6801082	6801082	246	JJ
6701420	67014	LRB67014	6801084	6801084	246	JH
6701421	67014	LRB67014	6801088	6801088	215	JK
6701422	67014	LRB67014	6801106	6801106	215	JU
6701423	67014	LRB67014	6801115	6801115	233	
6701424	67014	LRB67014	6801136	6801136	265	JV
6701428	67014	LRB67014	6801157	6801157	246	JY
6701429	67014	LRB67014	6801029	6801029	235	KA
6701430	67014	LRB67014	6801180	6801180	258	
6701501	67015	LRB67015	6801012	6801012	256	HD
6701502	67015	LRB67015	6801029	6801029	246	HM
6701503	67015	LRB67015	6801029	6801029	205	HX
6701504	67015	LRB67015	6801159	6801159	225	JZ

**INJECTOR LIST - Nov 07 - 27 of 36**

<b>Injector Desp No.</b>	<b>Holder Desp No.</b>	<b>Holder Type Symbol No.</b>	<b>Nozzle Desp No.</b>	<b>Nozzle Type Symbol No.</b>	<b>Injector Working Pressure ( Bar )</b>	<b>Tab Code</b>
6701601	67016	LRB67016	6801024	6801024	269	
6701602	67016	LRB67016	6801098	6801098	269	
6701801	67018	LRB67018	6801023	6801023	256	
6701802	67018	LRB67018	6801026	6801026	256	
6702101	67021	LRV67021	6801032	6801032	243	
6702501	67025	LCC67025	R5643410	RDN0SDC6577	118	
6702501C	67025	LCC67025	5643414	RDN0SDC6577C	117	
6702505C	67025	LCC67025	5641910	RDN0SDC6864C	130	
6702601	67026	LRB67026	6801040	6801040	200	
6702602	67026	LRB67026	6801041	6801041	200	
6702603	67026	LRB67026	6801042	6801042	200	
6702604	67026	LRB67026	6801043	6801043	207	
6702605	67026	LRB67026	6801044	6801044	207	
6702606	67026	LRB67026	6801067	6801067	200	
6702607	67026	LRB67026	6801116	6801116	200	
6702608	67026	LRB67026	6801117	6801117	200	
6702801	67028	LRC67028	6801049	6801049	212	
6702901	67029	LRB67029	6801050	6801050	247	
6702902	67029	LRB67029	6801051	6801051	247	
6702903	67029	LRB67029	6801054	6801054	247	
6702904	67029	LRB67029	6801076	6801076	247	
6702905	67029	LRB67029	6801137	6801137	258	
6703001	67030	LRB67030	6801061	6801061	220	JC
6703002	67030	LRB67030	6801062	6801062	220	JD
6703201	67032	LRB67032	6801052	6801052	247	JF
6703202	67032	LRB67032	6801057	6801057	227	JG
6703203	67032	LRB67032	6801093	6801093	247	JL
6703204	67032	LRB67032	6801100	6801100	247	JR
6703205	67032	LRB67032	6801084	6801084	247	JS
6703206	67032	LRB67032	6801104	6801104	247	JT
6703301	67033	LRB67033	6801063	BDLL136S6858	222	
6703302	67033	LRB67033	6801064	BDLL124S6857	222	
6703303	67033	LRB67033	6801065	BDLL138S6859	253	
6703304	67033	LRB67033	6801066	BDLL134S6860	253	
6703305	67033	LRB67033	6801146	BDLL138S6884	260	305
6703306	67033	LRB67033	6801147	BDLL134S6885	260	306
6703401	67034	LRC67034	5620840	BDLL150S6159	207	
6703501	67035	LRA67035	6801072	6801072	233	
6703502	67035	LRA67035	6801073	6801073	233	
6703503	67035	LRA67035	6801080	6801080	233	
6703505	67035	LRA67035	6801087	6801087	233	
6703506	67035	LRA67035	6801090	6801090	233	
6703507	67035	LRA67035	6801091	6801091	233	
6703508	67035	LRA67035	6801105	6801105	233	
6703509	67035	LRA67035	6801109	6801109	233	
6703510	67035	LRA67035	6801110	6801110	233	
6703511	67035	LRA67035	6801111	6801111	233	
6703512	67035	LRA67035	6801114	6801114	233	
6703513	67035	LRA67035	6801080	6801080	210	
6703514	67035	LRA67305	6801167	6801167	233	
6703801	67038	LRC67038	5643810	BDN0SD253	117	
6703901	67039	LRC67039	5643808	BDN0SD248	117	
6704001	67040	LRC67040	5643808	BDN0SD248	117	
6704201	Two stage	Two stage	Two stage	Two stage	refer Injector A47	

Injector Desp No.	Holder Desp No.	Holder Type Symbol No.	Nozzle Desp No.	Nozzle Type Symbol No.	Injector Working Pressure ( Bar )	Tab Code
6704301	67043	LRB67043	6801085	6801085	238	JM JN
6704302	67043	LRB67043	6801086	6801086	238	
6704303	67043	LRB67043	6801107	6801107	197	
6704304	67043	LRB67043	6801108E	6801108E	238	
6704401A	67044	LRT67044	6801172	6801172	185	
6704601	67046	LRB67046	6801061	6801061	220	
6704602	67046	LRB67046	6801062	6801062	220	
6704701	67047	LRC67047	6801077	6801077	248	
6704801	67048	LRA67048	6801134	6801134	230	
6704802	67048	LRA67048	6801135	6801135	230	
6704803	67048	LRA67048	6801133	6801133	230	
6704805	67048	LRA67048	6801135	6801135	282	
6704806	67048	LRA67048	6801148	6801148	230	
6704808	67048	LRA67048	6801148	6801148	282	
6704809	67048	LRA67048	6801165	6801165	282	
6704810	67348	LRA67048	6801170	6801170	230	
6704812	67048	LRA67048	6801158	6801158	230	
6704901	67049	LRB67049	6801138	6801138	233	
6705001	67050	LRB67050	6801141	6801141	240	
6705002	67050	LRB67050	6801179	6801179	235	
6705003	67050	LRB67050	L003CVA	L003CVA	265	
6705004	67050	LRB67050	L004CVA	L004CVA	255	
6705005	67050	LRB67050	L005CVA	L005CVA	265	
6705006	67050	LRB67050	L006CVA	L006CVA	265	
6705007	67050	LRB67050	L009CVA	L009CVA	265	
6705008	67050	LRB67050	L010CVA	L010CVA	265	
6705204	67052	LRB67052	6801155	6801155	240	
6705301C	67053	LRC67053	5643480	RDN12SDC6872C	151	
6705301E	67053	LCR67053	5643482	RDN12SDC6872E	148	
6705304	67053	LCR67053	5641930	RDN0SDC6897	145	
6705402D	67054	LCR67054	5643076	RDN12SDC6849D	118	
6705404D	67054	LCR67054	5641924	RDN0SDC6888D	128	
6705501	67055	LRB67055	6801175	6801175	210	
6705502	67055	LRB67055	6801176	6801176	210	
6705503	67055	LRB67055	6801177	6801177	210	
6705601E	67056	LCR67056	5643482	RDN12SDC6872E	148	
6705701D	67057	LCR67057	5643076	RDN12SDC6849D	118	
6730101	67301	LSB67301	5621771	BDLL150S6725	250	
6730104	67301	LSB67301	5621836	BDLL150S6789CF	250	
6730106	67301	LSB67301	5621872	BDLL150S6831CF	250	
6730201	67302	LSB67302	5621771	BDLL150S6725	243	
6730501	67305	LCB67305	5641892	RDN0SD6754	122	
6730504	67305	LCB67305	5641020	BDN0SD193	130	
6730701	67307	LCB67307	R5643410	RDN0SDC6577	116	
6730701B	67307	LCR67307	5643413	RDN0SDC6577B	105	
6730702	67307	LCR67307	5641891	RDN0SDC6751	116	
6730702C	67307	LCR67307	5641906	RDN0SDC6751C	125	
6730702D	67307	LCR67307	5641914	RDN0SDC6751D	125	
6730702E	67307	LCR67307	5641915	RDN0SDC6751E	125	
6730704	67307	LCR67307	5643075	RDN12SDC6849C	120	
6730704C	67307	LCR67307	5643075	RDN12SDC6849C	120	
6730705	67307	LCC67307	5641902	RDN0SDC6850	116	
6730705B	67307	LCR67307	5641903	RDN0SDC6850B	116	
6730705C	67307	LCR67307	5641904	RDN0SDC6850C	116	
6730705D	67307	LCR67307	5641919	RDN0SDC6850D	130	

Injector Desp No.	Holder Desp No.	Holder Type Symbol No.	Nozzle Desp No.	Nozzle Type Symbol No.	Injector Working Pressure ( Bar )	Tab Code
6730707C	67307	LCR67307	5643090	RDN12SDC6862C	131	
6730707D	67307	LCR67307	5643091	RDN12SDC6862D	131	
6730707E	67307	LCR67307	5643092	RND12SDC6862E	130	
6730708C	67307	LCR67307	5641909	RDN0SDC6863C	130	
6730708D	67307	LCR67307	5641925	RDN0SDC6863D	130	
6730709C	67307	LCR67307	5643480	RDN12SDC6872C	130	
6730709D	67307	LCR67307	5643481	RDN12SDC6872D	130	
6730709G	67307	LCR67307	5643493	RDN12SDC6872G	105	
6730710C	67307	LCR67307	5641916	RDN0SDC6880C	130	
6730711C	67307	LCR67307	5643480	RDN12SDC6872C	115	
6730712C	67307	LCR67307	5641927	RDN0SDC6890C	130	
6730712D	67307	LCR67307	5641931	RDN0SDC6890D	130	
6730801	67308	LCR67308	5641891	RDN0SDC6751	116	
6730901	67309	LCR67309	R5643410	RDN0SDC6577	116	
6730901B	67309	LCR67309	5643413	RDN0SDC6577B	116	
6731101	67311	LSB67311	6801008	6801008	233	
6731201	67312	LRC67312	5641892	RDN0SD6754	122	
6731203	67312	LRC67312	5641892	RDN0SD6754	147	
6731204	67312	LCB67312	5641025	BDN0SD293	155	
6731205	67312	LCB67312	5641025	BDN0SD293	130	
6731401	67314	LCB67314	5641892	RDN0SD6754	122	
6731501	67315	LSB67315	5621836	BDLL150S6789CF	250	
6731502	67315	LSB67315	5621897	BDLL150S6846CF	250	
6731503	67315	LSB67315	5621872	BDLL150S6831CF	261	
6731704	67317	LSC67317	5621849	BDLL150S6802CF	222	
6732001	67320	LRC67320	5641901	RDN0SDC6843	116	
6732001C	67320	LRB67320	5641905	RDN0SDC6843C	116	
6732201	67325	LRC67322	5641032	RDN0SD6827	127	
6732202	67325	LRC67322	5641907	RDN12SD6855	136	
6732401	67324	LRC67324	5641907	RDN12SD6855	127	
6732501	67325	LRC67325	5641907	RDN12SD6855	132	
6732502	67325	LRC67325	5641891	RDN0SDC6751	127	
6732601C	67326	LRC67326	5641904	RDN0SDC6850C	116	
6732602C	67326	LRC67326	5643075	RDN12SDC6849C	118	
6732603C	67326	LRC67326	5643075	RDN12SDC6849C	133	
6732604C	67326	LCR67326	5641906	RDN0SDC6751C	116	
6732701	67327	LCR67327	5643413	RDN0SDC6577B	116	
6732702	67327	LCR67327	5641904	RDN0SDC6850C	131	
6733001C	67330	LCR67330	5641905	RDN0SDC6843C	115	
6733001D	67330	LCR67330	5641922	RDN0SDC6843D	115	
6733101C	67331	LCR67331	5641906	RDN0SDC6751C	120	
6733301	67333	LRC67333	5641912	RDN0SD6866C	105	
6733302	67333	LRC67333	5641913	RDN0SD6867C	105	
6733401C	67334	LCR67334	5643321	RDN4SDC6868C	115	
6733401D	67334	LCR67334	5643324	RDN4SDC6868D	120	
6733402C	67334	LCR67334	5643322	RDN4SDC6878C	130	
6733402D	67334	LCR67334	5643325	RDN4SDC6878D	130	
6733501	67335	LCR67335	5641028	RDN0SD6871	120	
6733801	67338	LSB67338	5628921	BDLLA34S837	195	
6733802	67338	LSB67338	5628964	BDLLA136S943	213	
6733901	67339	LJC67339	6970001	BDN0PDN112	130	
6733902	67339	LJC67339	6970002	BDN0PDN21	118	
6734101	67341	LCR67341	5642049	BDN4S6873	130	
6734101D	67341	LCR67341	5642052	RDN4S6873D	130	
6734202D	67342	LCR67342	5641924	RDN0SDC6888D	120	

**INJECTOR LIST - Nov 07 - 30 of 36**

<b>Injector Desp No.</b>	<b>Holder Desp No.</b>	<b>Holder Type Symbol No.</b>	<b>Nozzle Desp No.</b>	<b>Nozzle Type Symbol No.</b>	<b>Injector Working Pressure ( Bar )</b>	<b>Tab Code</b>
6734203D	67342	LRB67342	5641924	RDN0SDC6888D	120	
6734301C	67343	LCR67343	5643100	RDN12SDC6874C	150	
6734302H	67343	LCR67343	5641926	RDN0SDC6751H	150	
6734303F	67343	LCR67343	5643491	RDN12SDC6872F	150	
6734303G	67343	LCR67343	5643493	RDN12SDC6872G	150	
6734501C	67345	LCR67345	5641906	RDN0SDC6751C	130	
6734801C	67348	LRC67348	5643075	RDN12SDC6849C	143	
6735101D	67351	LCR67351	5643326	RDN4SDC6886D	118	
6735201D	67352	LCR67352	5641921	RDN0SDC6887D	129	
6735202	67352	LCR67352	5643492	RDN12SDC6895	130	
6735203D	67352	LCR67352	5641924	RDN0SDC6888D	130	
6735204	67352	LCR67352	5643494	RDN12SDC6901	130	
6735205	67352	LCR67352	5641934	RDN0SDC6902	125	
6735301	67353	LSB67353	6801154	6801154	254	
6735302	67353	LSB67353	6801164	6801164	250	
6735303	67353	LSB67353	6801164	6801164	248	
6735304	67353	LSB67353	6801154	6801154	248	
6735306	67353	LSB67353	L013CVA	L013CVA	253	
6735401D	67354	LCR67354	5643325	RDN4SDC6878D	130	
6735404	67354	LRC67354	5643327	RDN0SDC6900	118	
6735405	67354	LRC67354	5641934	RDN0SDC6902	118	
6735406H	67354	LCR67354	5641926	RDN0SDC6751H	118	
6735501	67355	LRC67355	5621939	BDLLA142S6882	200	
6735502	67355	LRC67355	5621944	KDLLA142S6894	205	
6735601D	67356	LCR67356	5641925	RDN0SDC6863D	120	
6736001	67360	LCR67360	5641935	RDN0SDC6903	132	
6735801C	67358	LCR67358	5643075	RDN12SDC6849C	151	
6735901D	67359	LRC67358	5641925	RDN0SDC6863D	100	
6735902D	67359	LRC67358	5641925	RDN0SDC6863D	120	
6759801	67598	LRC67598	5641025	BDN0SD293	130	
6760101	67601	LJB67601	6801025	6801025	246	
6760102	67601	LJB67601	6801033	6801033	246	
6760103	67601	LJB67601	6801034	6801034	246	
6760201	67602	LJC67602	6801028	6801028	128	AA
6760301	67603	LJC67603	6801036	6801036	118	BB
6760401	67604	LJC67604	6801059	6801059	246	
6760402	67604	LJC67604	6801060	6801060	246	
6760403	67604	LJC67604	6801055	6801055	246	
6760404	67604	LJC67604	6801056	6801056	246	
6760405	67604	LJC67604	6801070	6801070	246	
6760406	67604	LJC67604	6801071	6801071	235	
6760407	67604	LJC67604	6801074	6801074	246	
6760408	67604	LJC67604	6801075	6801075	250	
6760409	67604	LJC67604	6801060	6801060	220	
6760410	67604	LJC67604	6801079	6801079	210	
6760411	67604	LJC67604	6801079	6801079	235	
6760412	67604	LJC67604	6801060	6801060	215	
6760413	67604	LJC67604	6801055	6801055	215	
6760414	67604	LJC67604	6801089	6801089	215	
6760416	67604	LJC67604	6801102	6801102	237	
6760417	67604	LJC67604	6801118	6801118	237	9322
6760418	67604	LJC67604	6801122	6801122	247	9309
6760419	67604	LJC67604	6801124	6801124	217	9324
6760420	67604	LJC67604	6801121	6801121	247	9307
6760421	67604	LJC67604	6801123	6801123	247	9313

<b>Injector Desp No.</b>	<b>Holder Desp No.</b>	<b>Holder Type Symbol No.</b>	<b>Nozzle Desp No.</b>	<b>Nozzle Type Symbol No.</b>	<b>Injector Working Pressure ( Bar )</b>	<b>Tab Code</b>
6760422	67604	LJC67604	6801124	6801124	247	9324
6760423	67604	LJC67604	6801125	6801125	247	9320
6760424	67604	LJC67604	6801127	6801127	253	9315
6760425	67604	LJC67604	6801128	6801128	212	9319
6760426	67604	LJC67604	6801128	6801128	237	9312
6760427	67604	LJC67604	6801121	6801121	217	9323
6760428	67604	LJC67604	6801129	6801129	237	9325
6760429	67604	LJC67604	6801131	6801131	237	1913
6760430	67604	LJC67604	6801171E	6801171E	237	
6760501	67605	LJC67605	6801079	6801079	210	
6760502	67605	LJC67605	6801055	6801055	246	
6760503	67605	LJC67605	6801056	6801056	246	
6760504	67605	LJC67605	6801060	6801060	246	
6760505	67605	LJC67605	6801059	6801059	246	
6760506	67605	LJC67605	6801075	6801075	250	
6760507	67605	LJC67605	6801079	6801079	235	
6760508	67605	LJC67605	6801070	6801070	246	
6760509	67605	LJC67605	6801071	6801071	235	
6760510	67605	LJC67605	6801055	6801055	215	
6760511	67605	LJC67605	6801060	6801060	215	
6760512	67605	LJC67605	6801079	6801079	215	
6760513	67605	LJC67605	6801089	6801089	210	
6760514	67605	LJC67605	6801103	6801103	210	
6760515	67605	LJC67605	6801112E	6801112E	210	
6760516	67605	LJC67605	6801071	6801071	210	
6760517	67605	LJC67605	6801118	6801118	237	
6760518	67605	LJC67605	6801119	6801119	212	
6760519	67605	LJC67605	6801130	6801130	212	
6760520	67605	LJC67605	6801121	6801121	247	
6760521	67605	LJC67605	6801123	6801123	247	
6760522	67605	LJC67605	6801124	6801124	247	
6760523	67605	LJC67605	6801125	6801125	247	
6760524	67605	LJC67605	6801127	6801127	253	
6760525	67605	LJC67605	6801128	6801128	212	
6760526	67605	LJC67605	6801128	6801128	237	
6760527	67605	LJC67605	6801130	6801130	212	
6760528	67605	LJC67605	6801118	6801118	212	
6760529	67605	LJC67605	6801131	6801131	212	
6760530	67605	LJC67605	6801145	6801145	212	
6760531	67605	LJC67605	6801131	6801131	237	
6760532	67605	LJC67605	6801150	6801150	212	
6760534	67605	LJC67605	6801171E	6801171E	212	
6760536	67605	LJC67605	L127CBA	L127CBA	236	
6760537	67605	LJC67605	6801124	6801124	273	
6760538	67605	LJC67605	L014CVA	L014CVA	238	
6760539	67605	LJC67605	L015CVA	L015CVA	238	
6760601	67606	LJB67606	6801034	6801034	246	
6760602	67606	LJB67606	6801033	6801033	246	
6760603	67606	LJB67606	6801025	6801025	246	
6760801	67608	LJC67355	5621939	BDLLA142S6882	211	
6761001	67610	LJC67610	6801160	6801160	249	
6761002	67610	LJC67610	6801161	6801161	249	
6761003	67610	LJC67610	6801174	6801174	238	
6761004	67610	LJC67610	6801173	6801173	238	
6761005	67610	LJC67610	L002CVA	L002CVA	238	

**INJECTOR LIST - Nov 07 - 32 of 36**

<b>Injector Desp No.</b>	<b>Holder Desp No.</b>	<b>Holder Type Symbol No.</b>	<b>Nozzle Desp No.</b>	<b>Nozzle Type Symbol No.</b>	<b>Injector Working Pressure ( Bar )</b>	<b>Tab Code</b>
6761006	67610	LJC67610	6801160	6801160	264	
6761202	67612	LJB67612	LP053B	LP053B	216	
001B01	001B	LJB001B	LP051B	LP051B	288	KB
001R02B	001R	LDC001R	NB001RB	NB001RB	105	
001R03A	001R	LDC001R	5641928	RDN0SD6891C	105	
001R04B	001R	LDC001R	NB003RB	NB003RB	106	
002B01	002B	LRB002B	LP052B	LP052B	282	KC
002R01AD2	Instrumented	Instrumented	Instrumented	Instrumented	refer to DT169	
002R01AE1	Instrumented	Instrumented	Instrumented	Instrumented	refer to DT169	
002R01AE2	Instrumented	Instrumented	Instrumented	Instrumented	refer to DT169	
003B01	003B	LRA003B	LP054B	LP054B	282	
003B02	003B	LRA003B	L067PBA	L067PBA	282	
003B03	003B	LRA003B	L073PBA	L073PBA	282	
003R01A	003R	LDC003R	NP002RA	NP002RA	156	
004B01	004B	LRB004B	LP055B	LP055B	282	KD
007R01A	007R	LDC007R	5643076	RDN12SDC6849D	135	
008R01AA2	Instrumented	Instrumented	Instrumented	Instrumented	refer to DT169	
009R01AA1	Instrumented	Instrumented	Instrumented	Instrumented	refer to DT169	
009R01AA2	Instrumented	Instrumented	Instrumented	Instrumented	refer to DT169	
010R01A	010R	LDC010R	5643076	RDN12SDC6849D	125	
010R01B	010R	LDC010R	5643077	RDN12SDC6849E	125	
011R02AA1	Instrumented	Instrumented	Instrumented	Instrumented	refer to DT169	
013R01AA1	Instrumented	Instrumented	Instrumented	Instrumented	refer to DT169	
B00601A	B006	LJCB006	L057PBA	L057PBA	286	KK
B00602A	B006	LJCB006	L058PBA	L058PBA	286	KL
B00701A	B007	LJCB007	L056PBA	L056PBA	286	KM
B00801A	B008	LJCB008	L059PBA	L059PBA	245	KJ
B00802A	B008	LJCB008	L063PBA	L063PBA	286	KN
B00803A	B008	LJCB008	L069PBA	L069PBA	286	KR
B00901A	B009	LJCB009	L060PBA	L060PBA	286	KF
B00902A	B009	LJCB009	L064PBA	L064PBA	286	KE
B00903A	B009	LJCB009	L070PBA	L070PBA	286	KT
B00904A	B009	LJCB009	L072PBA	L072PBA	286	KW
B00905A	B009	LJCB009	L064PBA	L064PBA	255	KX
B01001A	B010	LJCB010	L062PBA	L062PBA	286	KG
B01002A	B010	LJCB010	L061PBA	L061PBA	286	KH
B01201A	B012	LJCB012	L065PBA	L065PBA	284	KP
B01202A	B012	LJCB012	L064PBA	L064PBA	284	KU
B01301A	B013	LSCB013	L066PBA	L066PBA	254	
B01401A	B014	LJCB014	L068PBA	L068PBA	286	KS
B01501A	B015	LJCB015	L064PBA	L064PBA	286	KU
B01601A	B016	LRAB016	L067PBA	L067PBA	282	
B01702D	Two stage	TJBB017	L079PBD	L079PBD	refer to DT332	
B01901D	Two stage	TJBB019	L078PBD	L078PBD	refer to DT332	
B01902D	Two stage	TJBB019	L089PBD	L089PBD	refer to DT332	

**INJECTOR LIST - Nov 07 - 33 of 36**

<b>Injector Desp No.</b>	<b>Holder Desp No.</b>	<b>Holder Type Symbol No.</b>	<b>Nozzle Desp No.</b>	<b>Nozzle Type Symbol No.</b>	<b>Injector Working Pressure ( Bar )</b>	<b>Tab Code</b>
B02201D	Two stage	TJBB022	L076PBD	L076PBD	refer to DT332	KY
B02202D	Two stage	TJBB022	L081PBD	L081PBD	refer to DT332	
B02303D	Two stage	TJBB023	L077PBD	L077PBD	refer to DT332	
B02402A	B024	LJBB024	L095PBA	L095PBA	230	
B02501	B025	LJCB025	L104PBA	L104PBA	280	
B02601D	Two stage	TJBB026	L076PBD	L076PBD	refer to DT332	
B02602D	Two stage	TJBB026	L081PBD	L081PBD	refer to DT332	
B02701D	Two stage	TJBB027	L079PBD	L079PBD	refer to DT332	
B02801D	Two stage	TJBB028	L077PBD	L077PBD	refer to DT332	
B02901B	B029	LRBB029	L110PBB	L110PBB	290	
B02903B	B029	LRBB029	L126PBB	L126PBB	280	
B02904B	B029	LRBB029	L147PBB	L147PBB	315	
B02905B	B029	LRBB029	L148PBB	L147PBB	280	
B02906B	B029	LRBB029	L110PBB	L110PBB	290	
B02907B	B029	LRBB029	L126PBB	L126PBB	280	
B03001B	B030	LRBB030	L123PBB	L123PBB	235	
B03003B	B030	LRBB030	L123PBB	L123PBB	235	
B03004B	B030	LRBB030	L186PBB	L186PBB	235	
B03005B	B030	LRBB030	L191PBB	L191PBB	235	
B03006B	B030	LRBB030	L241PBB	L241PBB	235	
B03101	B031	LRBB031	6801157	6801157	243	
B03201A	B032	LJBB032	L130PBA	L130PBA	280	
B03202A	B032	LJBB032	L131PBA	L131PBA	280	
B03203A	B032	LJBB032	L159PBA	L159PBA	280	
B03301A	B033	LJBB033	L129PBA	L129PBA	280	
B03303A	B033	LJBB033	L277PBA	L277PBA	280	
B03401A	B034	LJBB034	L131PBA	L131PBA	refer to DT372/2	
B03304A	B033	LJBB033	L309PBA	L309PBA	280	
B03305A	B033	LJBB033	L292PBA	L292PBA	280	
B03501A	B035	LJBB035	L132PBA	L132PBA	refer to DT372/2	
B03502A	B035	LJBB035	L129PBA	L129PBA	refer to DT372/2	
B03601A	B036	LJBB036	L130PBA	L130PBA	280	
B03602A	B036	LJBB036	L129PBA	L129PBA	280	
B03701A	B037	LJCB037	L143PBA	L143PBA	240	
B03801A	B038	LJCB038	L144PBA	L144PBA	265	
B03901A	B039	LJBB039	L154PBA	L154PBA	280	
B04001A	B040	LJBB040	L155PBA	L155PBA	280	
B03902A	B039	LJBB039	L318PBA	L318PBA	210	
B04002A	B040	LJBB040	L255PBA	L255PBA	280	
B04101A	B041	LJBB041	L158PBA	L158PBA	280	
B04401A	B044	LJCB044	L192PBA	L192PBA	260	
B04402A	B044	LJCB044	L144PBA	L144PBA	260	
B04403A	B044	LJCB044	L192PBA	L192PBA	260	
B04404A	B044	LJCB044	L144PBA	L144PBA	260	
B04801A	B048	LJBB048	L276PBA	L276PBA	170	
G00101A	G001	LDCG001	5641930	RDN0SDC6897	115	
B05001A	B050	B050	L290PBA	L290PBA	210	

Injector Desp No.	Holder Desp No.	Holder Type Symbol No.	Nozzle Desp No.	Nozzle Type Symbol No.	Injector Working Pressure ( Bar )	Tab Code
B05002A	B050	LJBB050	L319PBA	L319PBA	210	
B05101A	B051	LJBB051	L289PBA	L289PBA	210	
B05201A	B052	LJBB052	L131PBA	L131PBA	280	
B05202A	B052	LJBB052	L326PBA	L326PBA	230	
B05301A	B053	LJBB053	L276PBA	L276PBA	170	
					refer to	
G00101AA1	Instrumented	Instrumented	Instrumented	Instrumented	DT169	
G00102A	G001	LDCG001	5641930	RDN0SDC6897	120	
G00201A	G002	LRBG002	L001SGA	L001SGA	220	
G00301A	G003	LJCG003	L003PGA	L003PGA	250	
G00302A	G003	LDCG003	N002SGA	N002SGA	110	
					refer to	
G00302AA1	Instrumented	Instrumented	Instrumented	Instrumented	DT169	
G00303A	G003	LDCG003	N002SGA	N002SGA	120	
G00401A	G004	LRBG004	L002SGA	L002SGA	200	
G00401A	G004	LDCG004	N001SGA	N001SGA	130	
G00402G	G004	LDCG004	5643493	RDN12SDC6872G	130	
G00501A	G005	LJCG005	L004PGA	L004PGA	280	
G00511A	G005	LJCG005	L008PGA	L008PGA	280	
G00601A	G006	LJBG006	L095PBA	L095PBA	280	
G00701A	G007	LRBG007	L005PGA	L005PGA	280	
G00801A	G008	LJCG008	L006PGA	L006PGA	260	
G00901A	G009	LJBG009	L007PGA	L007PGA	280	
G00911A	G009	LJBG009	L009PGA	L009PGA	280	
G02001G	G020	LRCG020	5643493	RDN12SDC6872G	137	
G02101C	G021	LRCG021	5641927	RDN0SDC6890C	130	
G02102C	G021	LRCG021	-----	-----	134	
R00001Z	C/Rail	EJDR000	L096PBD	L096PBD	C/Rail	
R00101Z	C/Rail	EJDR001	L096PBD	L096PBD	C/Rail	
R00201Z	C/Rail	EJDR002	L096PBD	L096PBD	C/Rail	
R00202Z	C/Rail	EJDR002	L128PBD	L128PBD	C/Rail	
R00301Z	C/Rail	EJDR003	L096PBD	L096PBD	C/Rail	
R00401Z	C/Rail	EJDR004	L096PBD	L096PBD	C/Rail	
R00402Z	C/Rail	EJDR004	L128PBD	L128PBD	C/Rail	
R00403Z	C/Rail	EJDR004	L145PBD	L145PBD	C/Rail	
R00501Z	C/Rail	EJDR005	L133PBD	L133PBD	C/Rail	
R00502Z	C/Rail	EJDR005	L134PBD	L134PBD	C/Rail	
R00504Z	C/Rail	EJDR005	L135PBD	L135PBD	C/Rail	
R00601D	C/Rail	EJDR006	L150PBD	L150PBD	C/Rail	
R00701D	C/Rail	EJDR007	L184PBD	L184PBD	C/Rail	
R00801D	C/Rail	EJDR008	L201PBD	L201PBD	C/Rail	
R00901Z	C/Rail	EJBR009	L097PBD	L097PBD	C/Rail	
R01001A	C/Rail	EJBR010	L109PBD	L109PBD	C/Rail	
R01001D	C/Rail	EJBR010	L096PBD	L096PBD	C/Rail	
R01001Z	C/Rail	EJBR010	L109PBD	L109PBD	C/Rail	
R01101D	C/Rail	EJBR011	L145PBD	L145PBD	C/Rail	
R01201Z	C/Rail	EJBR012	L087PBD	L087PBD	C/Rail	
R01301Z	C/Rail	EJBR013	C/Rail	C/Rail	C/Rail	
R01302Z	C/Rail	EJBR013	L121PBD	L121PBD	C/Rail	
R01401Z	C/Rail	EJBR014	L087PBD	L087PBD	C/Rail	
R01601Z	C/Rail	EJBR016	L121PBD	L121PBD	C/Rail	
R01701Z	C/Rail	EJBR017	L087PBD	L087PBD	C/Rail	
R01801A	C/Rail	EJBR018	L120PBD	L120PBD	C/Rail	
R01801Z	C/Rail	EJBR018	L120PBD	L120PBD	C/Rail	
R01901Z	C/Rail	EJBR019	L097PBD	L097PBD	C/Rail	

**INJECTOR LIST - Nov 07 - 35 of 36**

<b>Injector Desp No.</b>	<b>Holder Desp No.</b>	<b>Holder Type Symbol No.</b>	<b>Nozzle Desp No.</b>	<b>Nozzle Type Symbol No.</b>	<b>Injector Working Pressure ( Bar )</b>	<b>Tab Code</b>
R02001AB1	Instrumented	Instrumented	Instrumented	Instrumented	refer to DT169	
R02101AA1	Instrumented	Instrumented	Instrumented	Instrumented	refer to DT169	
R02101Z	C/Rail	EJBR021	L087PBD	L087PBD	C/Rail	
R02201AA1	Instrumented	Instrumented	Instrumented	Instrumented	refer to DT169	
R02201Z	C/Rail	EJBR022	L121PBD	L121PBD	C/Rail	
R02301AA1	Instrumented	Instrumented	Instrumented	Instrumented	refer to DT169	
R02301Z	C/Rail	EJBR023	L097PBD	L097PBD	C/Rail	
R02401A	R024	LDCR024	5641930	RDN0SDC6897	116	
R02401Z	C/Rail	EJBR024	L137PBD	L137PBD	C/Rail	
R02501AA1	Instrumented	Instrumented	Instrumented	Instrumented	refer to DT169	
R02501Z	C/Rail	EJBR025	L136PBD	L136PBD	C/Rail	
R02601AA1	Instrumented	Instrumented	Instrumented	Instrumented	refer to DT169	
R02601Z	C/Rail	EJBR026	L138PBD	L138PBD	C/Rail	
R02701Z	C/Rail	EJBR027	L146PBD	L146PBD	C/Rail	
R02801D	C/Rail	EJBR028	L097PBD	L097PBD	C/Rail	
R02901D	C/Rail	EJBR029	L137PBD	L137PBD	C/Rail	
R03001D	C/Rail	EJBR030	L136PBD	L136PBD	C/Rail	
R03101D	C/Rail	EJBR031	L153PBD	L153PBD	C/Rail	
R03301D	C/Rail	EJBR033	L163PBD	L163PBD	C/Rail	
R03401D	C/Rail	EJBR034	L157PBD	L157PBD	C/Rail	
R03501D	C/Rail	EJBR035	C/Rail	C/Rail	C/Rail	
R03601D	C/Rail	EJBR036	L097PBD	L097PBD	C/Rail	
R03701D	C/Rail	EJBR037	L137PBD	L137PBD	C/Rail	
R03801D	C/Rail	EJBR038	C/Rail	C/Rail	C/Rail	
R03902D	C/Rail	EJBR039	C/Rail	C/Rail	C/Rail	
R04001D	C/Rail	EJBR040	L120PBD	L120PBD	C/Rail	
R04101D	C/Rail	EJBR041	L087PBD	L087PBD	C/Rail	
R04201D	C/Rail	EJBR042	C/Rail	C/Rail	C/Rail	
R04301D	C/Rail	EJBR043	C/Rail	C/Rail	C/Rail	
R04601D	C/Rail	EJBR046	L138PBD	L138PBD	C/Rail	
R04401D	C/Rail	EJBR044	C/Rail	C/Rail	C/Rail	
R04501D	C/Rail	EJBR045	C/Rail	C/Rail	C/Rail	
R04601D	C/Rail	EJBR046	L138PBD	L138PBD	C/Rail	
R04701D	C/Rail	EJBR047	L157PBD	L157PBD	C/Rail	
R04901D	C/Rail	EJBR049	L260PBD	L260PBD	C/Rail	
R05001D	C/Rail	EJBR050	C/Rail	C/Rail	C/Rail	
R05101D	C/Rail	EJBR051	L153PBD	L153PBD	C/Rail	
R05102D	C/Rail	EJBR051	L291PRD	L291PRD	C/Rail	
R05201D	C/Rail	EJBR052	C/Rail	C/Rail	C/Rail	
R05301D	C/Rail	EJBR053	C/Rail	C/Rail	C/Rail	
R05501D	C/Rail	EJBR055	C/Rail	C/Rail	C/Rail	
T00101	T001	LRBT001	L001CTA	L001CTA	210	
T00301	T003	LJBT003	L003CTA	L003CTA	235	
T00302	T003	LJBT003	L004CTA	L004CTA	240	
T00303	T003	LJBT003	L015CTA	L015CTA	206	
T00401	T004	LJBT004	L003CTA	L003CTA	235	
T00402	T004	LJBT004	L004CTA	L004CTA	240	
T00501	T005	HDAT005	L005BTA	L005BTA	196	
T00601	T006	LDBT006	L006STA	L006STA	210	
T00601A	T006	LDBT006	L006STA	L006STA	210	

<b>Injector Desp No.</b>	<b>Holder Desp No.</b>	<b>Holder Type Symbol No.</b>	<b>Nozzle Desp No.</b>	<b>Nozzle Type Symbol No.</b>	<b>Injector Working Pressure ( Bar )</b>	<b>Tab Code</b>
T00701	T007	LSBT007	L007BTA	L007BTA	180	
T00702	T007	LSBT007	L034BTA	L034BTA	180	
T00802	T008	LRBT008	L013CTA	L013CTA	220	
T00803	T008	LRBT008	L014CTA	L014CTA	220	
T01601	T016	LJBT016	L031PTA	L031PTA	240	
T01602	T016	LJBT016	L024PTA	L024PTA	240	
T01606	T016	LJBT016	L038PTA	L038PTA	240	
T01607	T016	LJBT016	L039PTA	L039PTA	240	
T01608	T016	LJBT016	L040PTA	L040PTA	240	
T01610	T016	LJBT016	L041PTA	L041PTA	240	
T02201	T022	LJBT022	L035PTA	L035PTA	240	
T02202	T022	LJBT022	L036PTA	L036PTA	248	
V00001	V000	LJCV000	L007CVA	L007CVA	265	
V00002	V000	LJCV000	L008CVA	L008CVA	265	
V00201	V002	LRBV002	6801141	6801141	240	
V00202	V002	LRBV002	6801179	6801179	235	
V00203	V002	LRBV002	L003CVA	L003CVA	265	
V00204	V002	LRBV002	L004CVA	L004CVA	255	
V00205	V002	LRBV002	L005CVA	L005CVA	265	
V00206	V002	LRBV002	L006CVA	L006CVA	265	
V00207	V002	LRBV002	L009CVA	L009CVA	265	
V00208	V002	LRBV002	L010CVA	L010CVA	265	